

PHILIPS

True wireless headphones

Small buds. Great value

Natural sound. Dynamic bass

Pocket-sized charging case

IPX4 splash resistant

TAT1000BK



Feel the beat, love the fit

Hear your sounds perfectly. These True Wireless headphones use 13 mm drivers for lush sound and punchy bass and an AI mic for clear calls. With IPX4 splash resistance and a pocket-sized charging case for 18 hours play time.

True wireless earbuds. Essential comfort.

- Great sound with large 13 mm drivers
- Compatible with Bluetooth® 6.0 and Microsoft Swift Pair
- Pocket-sized charging case

Simply all you need

- Philips Headphones app. Customize your experience
- Warm, natural sound. Philips sound signature

Take your tunes. Make your calls.

- IPX4 splash resistant
- Up to 18 hours play time with the case
- Clear calls. They'll hear what you're saying

Specifications

Sound

Acoustic system: Closed
 Frequency range: 20 - 20,000 Hz
 Speaker diameter: 13 mm
 Impedance: 32 Ohm
 Maximum power input: 3 mW
 Sensitivity: 123db ± 3db (1kHz, 1mW)
 Driver type: Dynamic

Connectivity

Bluetooth version: 6.0
 Bluetooth profiles: HFP, A2DP, AVRCP
 Maximum range: Up to 10 m
 Supported codec: SBC

Outer Carton

Length: 21.20 cm
 Number of consumer packagings: 24
 Width: 18.40 cm
 Gross weight: 1.873 kg
 Height: 18.10 cm
 GTIN: 1 48 95229 17892 9
 Nett weight: 1.01 kg
 Tare weight: 0.863 kg

Convenience

Volume control
 Water resistance: IPX4
 Philips Headphones app support
 Mono mode for TWS
 Type of controls: Touch
 Microsoft Swift Pair

Power

Number of batteries: 3 pcs
 Music play time: 3.5 + 14.5 hour(s)
 Charging time: 2 hour(s)
 Fast charging time: 15 mins for 1 hr
 Battery type(Charging case): Lithium Polymer (built-in)
 Battery type(Earbud): Lithium Polymer (built-in)

Battery weight (Total): 7.56 g
 Battery capacity(Case): 300 mAh
 Battery capacity(Earbud): 30 mAh

Packaging dimensions

Height: 10.5 cm
 Packaging type: Carton
 Type of shelf placement: Hanging
 Width: 9.6 cm
 Depth: 2.8 cm
 Number of products included: 1
 EAN: 48 95229 17892 2
 Gross weight: 0.068 kg
 Nett weight: 0.042 kg
 Tare weight: 0.026 kg

Accessories

Quick Start Guide
 Charging case

Design

Color: Black
 Ear fitting: Earbud

Telecommunication

Microphone for call: 2 AI mics

Dimensions

Charging case dimension(WxDxH): 5.50 x 4.70 x 2.50 cm
 Earbud dimension(WxDxH): 4.50 x 3.50 x 1.70 cm
 Total weight: 0.039 kg

Voice assistant

Voice assistant compatible: Apple Siri, Google Assistant
 Voice assistant activation: Multi-Function touch
 Voice assistant support

Highlights

Small earbuds, great sound

Hear your sounds perfectly. These True Wireless headphones use 13 mm drivers for lush sound and punchy bass and an AI mic for clear calls. With IPX4 splash resistance and a pocket-sized charging case for 18 hours play time.

Bluetooth® 6.0

Compatibility with the latest Bluetooth® 6.0 devices lets you stream without annoying dips in the sound. Microsoft Swift Pair is supported too.

Pocket-sized charging case

The small charging case slips easily into a pocket, while Mono mode means you can use either earbud while the other one charges.

IPX4 splash resistant

Never mind the weather, an IPX4 rating means these earbuds are splash resistant so they don't mind a little rain!

18 hours play time with case

You get 4.5 hours play time from a full charge, and an extra 13.5 hours from the case. Pop the earbuds back in the case and they'll recharge fully in 2 hours. If you need a quick boost, just 15 minutes gives you an extra hour. The case can be charged via USB-C.

Clear calls

Your voice will come through clearly when you're on a call. A dedicated mic picks up the sound of your voice while a noise-reduction algorithm reduces some of the background noise from the world around you.

Philips Headphones app

Feel like your music's missing something? Our companion app features AI Neural EQ, an intuitive equalizer that lets you tweak the sound and explore different EQ settings using your fingertips. You can also use the app to activate Dynamic Bass, and more.

Philips sound signature

The custom drivers in these headphones are tuned to Philips sound signature, which brings you warm, natural sound with deep bass. Whatever you're listening to, you'll love what you hear.

