

PHILIPS

RO Water Station with Instant Heating

Reverse Osmosis
purification

Instant Hot purified water

3 temperature and 4 volume
presets

Reduces PFAS, Fluoride, Viruses,
Bacteria, Microplastics and much
more

NASA/ESA tested Aquaporin
Inside™

ADD6914WH



Purified water, ambient, 45°C, 85°C or 95°C

Aquaporin Inside™ removes 110 kinds of substances

Philips RO Water Dispenser: Pure water, instantly hot or ambient. Select volume via smart touch controls. 5L tap water tank for household use, filter-life indicator ensures fresh water daily. Advanced, space-saving design.

Instant Heating

- Instant Heating

Multiple Volume Selections

- Multiple Volume Selections

Installation-Free Countertop Design

- Installation-Free Countertop Design

Aquaporin Inside® RO Best-in-class filtration

- RO Filter Cartridge

5L large-capacity tap water tank

- 5L large-capacity tap water tank

Reverse Osmosis purification

RO Water Station with Instant Heating

ADD6914WH/79

Highlights

Multiple Volume Selections

Supports continuous flow and preset volumes of 150, 250, 350, and 500ml, making it easy to match different cup sizes and usage scenarios.

Instant Heating

Experience instant hot water with advanced heating technology, delivering your preferred temperature in seconds. Choose from four precise presets—Ambient, 45°C, 85°C, and Hot—to perfectly match every need: from refreshing drinks and sensitive baby formula to rich coffee and steeped tea.

5L large-capacity tap water tank

The 5L large-capacity tap water tank reduces refilling frequency for greater convenience, making it ideal for household use.

Installation-Free Countertop Design

Designed for effortless setup: requires no drilling or permanent plumbing. It adapts seamlessly to any environment with simple plug-and-play operation.

RO Filter Cartridge

Experience cleaner, safer water every day with Aquaporin Inside® technology. This breakthrough reverse osmosis filtration system harnesses the power of nature's own water channels, aquaporin proteins, for superior filtration down to 0.0001 microns. It reduces up to 110 contaminants*, ensuring you enjoy refreshing, pure-tasting water for your everyday needs. Achieves 99.999% viral removal rate, with powerful filtration of emerging contaminants including pesticides and microplastics.

Specifications

Filter specifications

Filter precision: down to 0.0001 microns

Filtration capacity: 2000L

Replacement filter cartridge: ADD535

Main filter media: RO

Filter lifetime: Up to 12 months

RO specifications: 50 Gallon

General specifications

Product Dimension (LxWxH): 183*430*386 mm

Heating Type: Instant Heating

Water temperature: Ambient, 45°C, 85°C, Hot °C

Water volume: 150, 250, 350, 500mL

Raw water tank: 5L

Filter lifetime indicator

Input water temperature: 5-38°C °C

Rated power(heating): 2380 W

