

# PHILIPS



## True wireless headphones

Small buds. Comfort fit

Active Noise Canceling

4-mic technology

Natural sound. Dynamic bass



TAT2200LB

## Tune out the noise, love the fit

Flow through your days with the true wireless earbuds that feel lighter, fit better, and sound great. Active noise canceling lets you listen free from distractions, while textured ear tips keep the buds comfortably in place.

### **True wireless earbuds. Essential noise canceling.**

- Great sound from the everyday buds that fit like a dream
- Comfy SecureFit ear tips and large 10 mm drivers
- 4-mic technology. Clearer calls, even in crowded places
- Always hear your music with Active Noise Canceling
- Bluetooth® multipoint connectivity and easy pairing

### **Your daily go-to**

- Bluetooth® 6.0, Google Fast Pair, Microsoft Swift Pair
- IPX4 splash and sweat resistant
- Pocket-sized charging case with lanyard hole
- Up to 36 hours play time with case

### **Ready for you**

- Philips Headphones app. Customize your experience
- GRS-certified recycled plastic. Responsible packaging
- Warm, natural sound. Philips sound signature

# Highlights

## Small earbuds, great sound



SecureFit textured ear tips bring you a fit that feels lighter and more comfortable, while creating a good seal for even better sound. Features like Dynamic Bass will let you enjoy the full power of your favorite tunes even if listening quietly.

## 4-mic technology



These headphones boast a four-mic setup, and two of those mics plus an AI noise-reduction algorithm combine to bring you super-clear calls. Even if you're in a busy cafe, your voice will come

through clearly and the person you're speaking to won't be distracted by what's going on around you.

## Philips Headphones app

Feel like your music's missing something? Our companion app features EQ, an intuitive equalizer that lets you tweak the sound and explore different EQ settings using your fingertips. You can also use the app to activate Dynamic Bass, manage connected devices, update firmware, and more.

## Recycled materials

We use post-consumer recycled plastics in our products, and our packaging is made from FSC-certified recycled cardboard with inserts printed on recycled paper.

## Active Noise Canceling

Active noise cancellation reduces external noise so you can focus on your tunes, podcasts, and calls. You can turn it on or off via the earbuds, or our companion app, and Awareness Mode will let outside sounds back in.

## Bluetooth® 6.0

Compatibility with the latest Bluetooth® 6.0 devices lets you stream without annoying dips in the sound, and you can connect to two devices at once. Google Fast Pair and Microsoft Swift Pair are supported too.

## IPX4 splash/sweat resistant

Never mind the weather, an IPX4 rating means these earbuds are splash resistant so they don't mind a little rain! Wearing them on a particularly hot day? They won't mind a little sweat either.

## Pocket-sized charging case

The small charging case slips easily into a pocket, or you can attach a strap to the lanyard hole and hang the case from your bag or belt loop. Mono mode means you can use either earbud while the other one charges.

## 36 hours play time (8 + 28)

With noise canceling off, you get 8 hours play time from a full charge and an extra 28 hours from the charging case (with noise canceling on, you get 6 hours and an extra 21 from the case). For a quick boost, 10 minutes in the case gives you an extra 2 hours. The case can be charged via USB-C.

## Philips sound signature

The custom drivers in these headphones are tuned to Philips sound signature, which brings you warm, natural sound with deep bass. Whatever you're listening to, you'll love what you hear.

# Specifications

## Sound

Frequency range: 20 - 20,000 Hz  
Speaker diameter: 10 mm  
Impedance: 16 Ohm  
Maximum power input: 3 mW  
Sensitivity: 105db±2db (1kHz, 126mV)  
Driver type: Dynamic

## Connectivity

Bluetooth version: 6.0  
Bluetooth profiles: A2DP, AVRCP, HFP  
Maximum range: Up to 10 m  
Multipoint connection  
Supported codec: SBC

## Outer Carton

Length: 43.50 cm  
Number of consumer packagings: 24  
Width: 24.50 cm  
Gross weight: 2.95 kg  
Height: 12.50 cm  
GTIN: 1 48 95229 17818 9  
Nett weight: 1.42 kg  
Tare weight: 1.53 kg

## Convenience

Volume control  
Water resistance: IPX4  
Philips Headphones app support  
Mono mode for TWS  
Firmware updates possible  
Type of controls: Touch  
Google Fast Pair  
Microsoft Swift Pair

## Inner Carton

Length: 11.30 cm  
Number of consumer packagings: 3  
Width: 10.40 cm  
Height: 10.00 cm  
Nett weight: 0.18 kg  
Gross weight: 0.32 kg  
Tare weight: 0.14 kg  
GTIN: 2 48 95229 17818 6

## Power

Number of batteries: 3 pcs  
Charging time: 2 hour(s)  
Music play time (ANC on): 6 + 21 hour(s)

Music play time (ANC off): 8 + 28 hour(s)  
Fast charging time: 10 mins for 2 hrs  
Battery type(Charging case): Lithium Polymer (built-in)  
Battery type(Earbud): Lithium Polymer (built-in)  
Battery weight (Total): 10.1 g  
Battery capacity(Case): 410 mAh  
Battery capacity(Earbud): 50 mAh

## Packaging dimensions

Height: 11.2 cm  
Packaging type: Carton  
Type of shelf placement: Hanging  
Width: 9.6 cm  
Depth: 3.4 cm  
Number of products included: 1  
EAN: 48 95229 17818 2  
Gross weight: 0.085 kg  
Nett weight: 0.059 kg  
Tare weight: 0.026 kg

## Accessories

Quick Start Guide  
Eartips: 3 pairs (S/M/L)  
Charging case

## Design

Color: Light Blue  
Wearing style: In-ear  
Ear coupling material: Silicone  
Ear fitting: In-ear  
In-ear fitting type: Silicone ear tip

## Telecommunication

Microphone for call: 2 mics for each side

## Dimensions

Charging case dimension(WxDxH): 3.83 x 2.65 x 5.73 cm  
Earbud dimension(WxDxH): 1.51 x 2.16 x 1.87 cm  
Total weight: 0.034 kg

## ANC features

ANC technology: FF  
Awareness mode  
Microphone for ANC: 2 mic  
ANC (Active Noise Canceling)

## Voice assistant

Voice assistant compatible: Apple Siri, Google Assistant  
Voice assistant activation: Multi-Function touch  
Voice assistant support

## Sustainability

Plastic shell: contains 55% GRS certified recycled post-consumer Polycarbonate TE-00132492

