

# PHILIPS

## True wireless headphones

Small buds. Comfort fit.

Adaptive Noise Cancelling

6 mic technology

Detailed, natural sound

TAT3000WT



## Set the vibe, love the fit

Listen freely with true wireless earbuds that feel lighter, fit better and sound rich, warm and detailed. Adaptive Noise Cancelling responds to your surroundings, while Cafe and Lounge modes let your music hang back and set the vibe.

### **True wireless earbuds. Adaptive noise cancelling**

- Detailed sound, comfort fit, and Spatial Audio modes
- Comfy SecureFit ear tips and large 10 mm drivers
- Immerse freely with Adaptive Noise Cancelling
- Stable Bluetooth® multipoint connection and Auracast™
- 6 mic technology. Clearer calls, even in crowded places

### **Your daily go-to**

- IPX4 splash and sweat resistant
- Up to 48 hours of play time. Pocket-sized charging case
- Quick charge for 10 minutes and get an extra 2 hours

### **Ready for you**

- Philips Headphones app. Customise your experience
- GRS-certified recycled plastic. Responsible packaging
- Warm, natural sound. Philips sound signature

# Highlights

## Small earbuds, detailed sound

SecureFit textured eartips bring you a fit that feels lighter and more comfortable, while creating a good seal for even better sound.

Philips Spatial Audio features include Cafe and Lounge modes, which make your music sound like part of the background ambience: great for focusing on a task while listening.

## Adaptive Noise Cancelling

Adaptive noise cancellation quickly reacts to your surroundings to suppress external noise, including wind, in real time. If you want to hear what's going on around you, Awareness Mode lets outside sounds back in. Quick Awareness enhances voices, so you can have a conversation without removing your headphones.

## Bluetooth® 6.0, Auracast™

Bluetooth® 6.0 ensures a fast, steady connection, and support for Auracast™ lets you listen to public broadcasts on your travels. You can connect to two Bluetooth® devices at once and

manage connected devices via our app—plus Microsoft Swift Pair makes life easy for Windows users.

## 6 mic technology

These headphones boast a six-mic setup, and three of those mics plus an AI noise-reduction algorithm combine to bring you super-clear calls. Even if you're in a busy cafe, your voice will come through clearly and the person you're speaking to won't be distracted by what's going on around you.

## IPX4 splash/sweat resistant

Never mind the weather, an IPX4 rating means these earbuds are splash resistant so they don't mind a little rain! Wearing them on a particularly hot day? They won't mind a little sweat either.

## 48 hours of play time (12 + 36)

With noise cancelling off, you get 12 hours of play time from a full charge and an extra 36 hours from the pocket-sized charging case (with noise cancelling on, you get 8 hours and an

extra 24 from the case). For a quick boost, 10 minutes of charging gives you an extra 2 hours. The case can be charged via USB-C.

## Philips Headphones app

Feel like your music's missing something? Our companion app features EQ, an intuitive equalizer that lets you tweak the sound and explore different EQ settings using your fingertips. You can also use the app to activate Dynamic Bass, manage connected devices, update firmware and more.

## Philips sound signature

The custom drivers in these headphones are tuned to the Philips sound signature, which brings you warm, natural sound with deep bass. Whatever you're listening to, you'll love what you hear.

## Recycled materials

We use post-consumer recycled plastics in our products, and our packaging is made from FSC-certified recycled cardboard with inserts printed on recycled paper.

# Specifications

## Sound

Frequency range: 20 - 20,000 Hz  
Speaker diameter: 10 mm  
Impedance: 32 Ohm  
Maximum power input: 5 mW  
Sensitivity: 106 dB (1 kHz, 179 mV)  
Driver type: Dynamic

## Connectivity

Bluetooth version: 6.0  
Bluetooth profiles: HFP, A2DP, AVRCP  
Maximum range: Up to 10 m  
Multipoint connection  
Supported codec: SBC, LC3

## Outer Carton

Length: 26.50 cm  
Number of consumer packages: 24  
Width: 23.00 cm  
Gross weight: 3.05 kg  
Height: 22.50 cm  
GTIN: 1 48 95229 17895 0  
Net weight: 1.57 kg  
Tare weight: 1.48 kg

## Convenience

Volume control  
Water resistance: IPX4  
Philips Headphones app support  
Mono mode for TWS  
Firmware updates possible  
Type of controls: Touch  
Google Fast Pair  
Microsoft Swift Pair

## Inner Carton

Length: 12.30 cm  
Number of consumer packages: 3  
Width: 10.05 cm  
Height: 10.00 cm  
Net weight: 0.20 kg  
Gross weight: 0.336 kg  
Tare weight: 0.136 kg  
GTIN: 2 48 95229 17895 7

## Power

Number of batteries: 3 pcs  
Charging time: 2 hour(s)  
Music play time (ANC on): 8 + 24 hour(s)  
Music play time (ANC off): 12 + 36 hour(s)  
Fast charging time: 10 mins for 2 hrs

Battery type (Charging case): Lithium Polymer (built-in)  
Battery type (Earbud): Lithium Polymer (built-in)  
Battery weight (Total): 13.27 g  
Battery capacity (Case): 600 mAh  
Battery capacity (Earbud): 60 mAh

## Packaging dimensions

Height: 10.9 cm  
Packaging type: Carton  
Type of shelf placement: Hanging  
Width: 9.6 cm  
Depth: 3.55 cm  
Number of products included: 1  
EAN: 48 95229 17895 3  
Gross weight: 0.093 kg  
Net weight: 0.066 kg  
Tare weight: 0.027 kg

## Accessories

Quick Start Guide  
Eartips: 3 pairs (S/M/L)  
Charging case

## Design

Colour: White  
Wearing style: In-ear  
Ear coupling material: Silicone  
Ear fitting: In-ear  
In-ear fitting type: Silicone ear-tip

## Telecommunication

Microphone for call: 3 mics for each side

## Dimensions

Charging case dimension (W x D x H): 6.21 x 2.80 x 4.89 cm  
Earbud dimension (W x D x H): 3.21 x 2.38 x 2.07 cm  
Total weight: 0.052 kg

## UPC

UPC: 8 40063 20827 8

## ANC features

ANC technology: Hybrid  
Awareness mode  
Adaptive ANC  
Microphone for ANC: 2 mic  
ANC (Active Noise Cancelling)

## Voice assistant

Voice assistant compatible: Apple Siri, Google Assistant  
Voice assistant activation: Multi-Function touch  
Voice assistant support

## Sustainability

Plastic shell: contains 57% recycled post-consumer Polycarbonate TE-00132492

