

PHILIPS

CD Soundmachine

Multi-source CD player

CDs, DAB+/FM radio, USB

Bluetooth® 6.0, audio-in

Built-in cassette player

TAZ2500



Plays tapes, and everything else too

Ready to embrace the tape revival? This portable boombox features an integrated cassette deck as well as a CD player. You also get clear DAB+/FM radio, steady Bluetooth® streaming, USB playback and an audio-in port for other devices.

Portable multi-source CD player

- Portable boombox-style CD player
- Plays all CD formats: CDs, CD-R, CD-RW
- DAB+/FM radio. Digital tuning with up to 20 presets
- Easy wireless streaming via Bluetooth®
- Tape deck on board

Easy to place. Plays what you love.

- Connect to other sources via USB port and audio-in
- Two 2.5" speaker drivers. 6 W max (3 W RMS)
- Built-in carrying handle. Operates via AC or batteries*
- Stereo sound with Dynamic Bass Boost
- Integrated sleep timer

Made with environmentally friendly materials

- GRS-certified recycled plastic. Responsible packaging
- Dimensions: 285 x 125 x 245 mm

Specifications

Sound

Output power (RMS): 3W
 Sound Enhancement: Dynamic Bass Boost
 Sound System: Stereo
 Speaker diameter: 2.5"
 Volume Control: up/down

Loudspeakers

Built-in speakers: 2

Connectivity

USB: Type-A (playback)
 Bluetooth profiles: A2DP, AVRCP
 Audio in (3.5 mm)
 Bluetooth version: 6.0

Tuner/Reception/Transmission

Antenna: FM Antenna
 Auto digital tuning
 Tuner bands: FM mono, FM stereo, DAB/DAB+
 Station presets: 20 (FM) + 20 (DAB)
 RDS: Programme Type, Radio Text, Station Name
 Antenna type: Telescopic
 DAB/DAB+: Info display, Menu, Smart scan

Convenience

Display Type: LCD
 Backlight colour: White
 Sleep timer

Power

Battery type: LR14
 Battery voltage: 1.5 V
 Mains power: 100 V - 240 V, 50/60 Hz
 Standby power consumption: <0.8 W (clock display on)
 Number of batteries: 6*
 Power type: AC; batteries*

Accessories

Quick start guide
 Power cord
 Warranty: Warranty leaflet, Safety sheet

Design

Colour: Black

Dimensions

Packaging Depth: 159 mm
 Product depth: 245 mm
 Weight incl. Packaging: 2.2 kg
 Packaging Height: 278 mm
 Packaging Width: 370 mm
 Product width: 285 mm
 Product height: 125 mm
 Product weight: 1.35 kg

Audio Playback

Cassette Deck Technology: Mechanical
 Disc Playback Modes: Fast Forward/Reverse, Next/Previous Track Search, Repeat/Shuffle/Programme
 Playback Media: CD, CD-R, CD-RW
 Number of decks: 1
 USB Direct Modes: Play/Pause, Previous/Next, Fast Reverse/Fast Forward, Stop, Repeat, Shuffle, Programme Play
 Loader Type: Top
 Programmable Tracks: 20
 Bluetooth mode: Play/Pause, Previous/Next

Compatibility

Smartphone/tablet APP control: No

Sustainability

Plastic shell: contains 85% GRS-certified recycled post-consumer Acrylonitrile Butadiene Styrene (ABS) TE-00132492

Highlights

Portable CD player

Whether you're discovering the joy of physical CDs for the first time or all over again, this top-loading CD player is a great choice for casual listening. It can read any kind of CD format, and the carry handle makes it easy to move around. Simply plug into an AC socket or insert six batteries* (type R14 C) and take it outside.

DAB+/FM radio

When you want to embrace the music source that's been around longer than CDs, the digital tuner makes it easy to find the DAB+ or FM radio stations to love. You can set up to 20 DAB+ and 20 FM presets for the stations you listen to frequently.

Bluetooth® 6.0

Want to use this CD player as a portable speaker? Bluetooth® connectivity lets you stream sounds directly to the player from a compatible smart device, and Dynamic Bass Boost will rock your favourite basslines.

Built-in cassette player

The front-loading cassette player adds another way to listen. Whether you've held onto your mix tapes over the years or you're listening to cassettes for the first time, slip in a tape, press play and let the music roll.

USB playback, audio-in

For complete flexibility, there's also a USB port that lets you plug in a flash drive to enjoy your digital music collection. Or use the audio-in port to connect a turntable and play some records.

Sleep timer

If you like to drift off to sleep with music, an audiobook or the radio playing in the background, you can set the sleep timer for 120, 90, 60, 30 or 15 minutes. The CD player will enter standby mode after that time has elapsed.

Recycled materials



We use post-consumer recycled plastics in our products, and our packaging is made from FSC-certified recycled cardboard with inserts printed on recycled paper.

* This product has a battery compartment, but batteries are not included. Please purchase separately.

