

# PHILIPS



On-ear wireless  
headphones

Moving Sound

Striking sound. Retro looks  
Listen wireless or wired  
Up to 26 hours of play time  
USB-C cable included



TAMS1YL

## The Ringo Duo

Featherlight headphones with an iconic 80s design and striking modern-day sound. You can wear them wireless or rock them wired, and they come with black, yellow and orange ear-cup cushions to maximise the retro vibes.

### Moving Sound on-ear headphones. Live Loud.

- An 80s icon, reinvented
- Wireless or wired. Included USB-C cable with in-line mic
- Custom-tuned 40 mm drivers for rich warm sound
- Featherlight fit and spare ear-cup cushions in retro hues

### Rock them wireless or wired

- Long battery life and quick charging
- Stable Bluetooth® multipoint connection and easy pairing
- Clear calls. They'll hear what you're saying
- Handy on-ear button controls

### Modern-retro flair. 100 years of Philips sound.

- Philips Headphones app. The Ringo Duo companion
- Warm, natural sound. Philips sound signature
- RCS-certified recycled plastic. Responsible packaging

# Moving Sound

On-ear wireless headphones

## Specifications

### Sound

Acoustic system: Closed  
Frequency range: 20 - 20,000 Hz  
Impedance: 32 Ohm  
Maximum power input: 10 mW  
Sensitivity: 123 dB (1 kHz)  
Speaker diameter: 40 mm  
Driver type: Dynamic

### Connectivity

Bluetooth version: 6.0  
Bluetooth profiles: A2DP, AVRCP, HFP  
Maximum range: Up to 10 m  
Multipoint connection  
Supported codec: SBC

### Outer Carton

Length: 19.90 cm  
Number of consumer packages: 3  
Width: 18.50 cm  
Gross weight: 0.89 kg  
Height: 22.70 cm  
GTIN: 1 48 95229 17978 0  
Net weight: 0.33 kg  
Tare weight: 0.56 kg

### Convenience

Volume control  
Philips Headphones app support  
Firmware updates possible  
Type of controls: Button

### Power

Number of batteries: 1 pcs  
Music play time: 26 hour(s)  
Charging time: 2 hour(s)  
Fast charging time: 15 mins for 6hrs  
Battery weight (Total): 5 g  
Battery capacity (Headphones): 200 mAh  
Battery type (Headphones): Lithium Polymer (built-in)

### Packaging dimensions

Height: 21.3 cm  
Packaging type: Carton  
Type of shelf placement: Hanging

Width: 16.8 cm  
Depth: 6 cm  
Number of products included: 1  
EAN: 48 95229 17978 3  
Gross weight: 0.23 kg  
Net weight: 0.11 kg  
Tare weight: 0.12 kg

### Product dimensions

Height: 15.50 cm  
Width: 14.70 cm  
Depth: 5.00 cm  
Weight: 0.08 kg

### Accessories

Others: 2 pairs of extra cushion  
Audio cable: USB-C audio cable with control, L=1.2 m  
Quick Start Guide

### Design

Colour: Yellow  
Wearing style: Headband  
Foldable design: Flat  
Ear coupling material: Foam  
Ear fitting: On-ear  
Earcup type: Closed-back

### Telecommunication

Microphone for call: 1 mic

### UPC

UPC: 8 40063 20846 9

### Voice assistant

Voice assistant compatible: Apple Siri, Google Assistant  
Voice assistant activation: Press Play/Pause button  
Voice assistant support

### Sustainability

Plastic shell: contains 45% RCS certified recycled post-consumer Acrylonitrile Butadiene Styrene TE-00132492

TAMS1YL/00

## Highlights

### Striking sound. Retro looks

The look says rewind. The sound says right now. With their custom-tuned 40 mm drivers, these on-ear headphones bring you a warm sound with rich bass and clear vocals. Listen wireless or use the included USB-C cable to rock them wired.

### Modern comfort

The Ringo Duo headphones weigh just 80 g and the featherlight headband easily adjusts for the perfect fit. You get three sets of spare ear cushions in black, yellow and orange, so you can mix and not match.

### Up to 26 hrs of play time

You get up to 26 hours of play time from a full charge, which takes 2 hours via USB-C. If you need a quick boost, charging these on-ear headphones for just 15 minutes will get you an extra 6 hours of play time.

### Bluetooth® 6.0

Compatibility with the latest Bluetooth® 6.0 devices lets you stream without annoying dips in the sound, and you can connect to two devices at once. Simply use the Philips Headphones app to manage your connected devices.

### Clear calls

The Ringo Duo are born to say hello. For wireless calls, a dedicated mic picks up the sound of your voice while a noise-reduction algorithm reduces some of the background noise. For wired calls, there's an in-line mic with a handy mute button on the included USB-C cable.

### On-ear controls

Back in the day, you had to push big, clunky buttons on your cassette player to control the music! Now you get handy button controls on the earcups for playback, volume and calls.

### Philips Headphones app

Feel like your music's missing something? Our companion app features EQ, an intuitive equalizer that lets you tweak the sound and explore different EQ settings using your fingertips. You can also use the app to manage connected devices, update firmware and more.

### Philips sound signature

Glossary/feature highlight: The custom drivers in these headphones are tuned to Philips sound signature, which brings you warm, natural sound with deep bass. Whatever you're listening to, you'll love what you hear.

### Recycled materials

We use post-consumer recycled plastics in our products, and our packaging is made from FSC-certified recycled cardboard with inserts printed on recycled paper.

