

PHILIPS

Hanging Air
Conditioner

Cb5 wall-mounted AC

WiFi Intelligent Control

Cold Plasma

Smart Core Self-clean

FAC18FDCB5CCA1TH



Cb5 wall-mounted AC

Non-inverter, cooling

Smart

- Auto Restart with Memory
- WiFi Intelligent Control

Clean

- Smart Core Self-clean
- Filter Dirty Alarm
- Cold Plasma

Quiet

- DN Multi-Dimensional Noise Reduction System

Efficient

- Turbo Cooling

Caring

- Sleep Mode
- Automatic 4-way Swing

Cb5 wall-mounted AC

Hanging Air Conditioner

Highlights

Auto Restart with Memory

Automatically restores previous settings (mode, temperature, fan speed, and swing) after a power outage—no need to reset manually.

Turbo Cooling

Delivers powerful cooling in as fast as 30 seconds, quickly creating a comfortable environment.

Smart Core Self-clean

Automatically captures moisture from the air to deeply clean the evaporator. This not only delivers cleaner airflow but also ensures long-lasting, powerful operation of the core.

Filter Dirty Alarm

Smart reminder after 1,000 hours of operation alerts you to clean the filter, ensuring optimal performance and healthier airflow.

WiFi Intelligent Control

Connect to the Philips CoolHome App for convenient remote operation. Adjust settings anytime, anywhere for effortless comfort.

DN Multi-Dimensional Noise Reduction System

Optimized air duct design, advanced refrigerant flow, and structural engineering minimize noise for whisper-quiet operation.

Sleep Mode

Automatically adjusts cooling based on ambient temperature and body temperature for a quieter, more restful night's sleep.

Cold Plasma

Releases high-energy ions that break down harmful particles and neutralize bacteria, ensuring double-layer sterilization and fresher indoor air.

Automatic 4-way Swing

Automatic up-down and left-right sweep delivers personalized airflow to suit different preferences and age groups.

LED Backlight Display

Easy-to-read LED display for clear visibility, even at night.

FAC18FDCB5CCA1TH/56

Specifications

Classification

Air conditioning: Split air conditioning

Sustainable

Charged Volume(g): 1230

Technical Specification

Voltage: 220-240 V

Frequency: 50Hz

Type: 1

Cooling T1

Power Input(W): 1472

Running Current(A): 6.5, 6.5

EER(W/W): 3.6

EER(Btu/h/W): 12.30

Capacity(Btu/h): 18100

Capacity(W/W): 5305

Indoor Unit

Sound Levels(S/H/M/L/SL)(dB(A)):

51/47/42/37/33

Air Circulation(S/H/M/L/SL)(m³/h):

1070/950/800/660/570

Net Dimension(WxHxD)(mm): 986x312x218

Package Dimension(WxHxD)(mm):

1076X314X399

Net/Gross Weight(kg): 12/15

Cooling T3

Capacity(W): 4660

Capacity(Btu/h): 15900

Power Input(W): 1765

Running Current(A): 7.6

EER(W/W): 2.64

EER(Btu/h/W): 9.01

Outdoor Unit

Sound Levels(H)(dB(A)): 55

Net Dimension(WxHxD)(mm): 913X608X384

Package Dimension(WxHxD)(mm):

965X645X421

Net/Gross Weight(kg): 42.5/46.0

Piping Connection

Liquid(mm(inch)): ϕ 6.35(1/4)

Gas(mm(inch)): ϕ 12.7(1/2)

Chargeless Pipe Length

Chargeless Pipe Length(m): 5

Maximum Pipe Length

Maximum Pipe Length(m): 20

Maximum elevation Length

Maximum elevation Length(m): 10

© 2026 Koninklijke Philips N.V.
All Rights reserved.

Issue date 2026-04-06
Version: 4.4.1

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

EAN: 69 37528 80980 5

www.philips.com

