

PHILIPS

Hanging Air
Conditioner

Cb5 wall-mounted AC

WiFi Intelligent Control

Cold Plasma

Smart Core Self-clean

FAC24FECB5CCA1TH



Cb5 wall-mounted AC

Non-inverter, cooling

Smart

- WiFi Intelligent Control
- Auto Restart with Memory

Clean

- Cold Plasma
- Filter Dirty Alarm
- Smart Core Self-clean

Quiet

- DN Multi-Dimensional Noise Reduction System

Efficient

- Turbo Cooling

Caring

- Sleep Mode
- Automatic 4-way Swing

Cb5 wall-mounted AC

Hanging Air Conditioner

Highlights

WiFi Intelligent Control

Connect to the Philips CoolHome App for convenient remote operation. Adjust settings anytime, anywhere for effortless comfort.

DN Multi-Dimensional Noise Reduction System

Optimized air duct design, advanced refrigerant flow, and structural engineering minimize noise for whisper-quiet operation.

Sleep Mode

Automatically adjusts cooling based on ambient temperature and body temperature for a quieter, more restful night's sleep.

Automatic 4-way Swing

Automatic up-down and left-right sweep delivers personalized airflow to suit different preferences and age groups.

Cold Plasma

Releases high-energy ions that break down harmful particles and neutralize bacteria, ensuring double-layer sterilization and fresher indoor air.

LED Backlight Display

Easy-to-read LED display for clear visibility, even at night.

Filter Dirty Alarm

Smart reminder after 1,000 hours of operation alerts you to clean the filter, ensuring optimal performance and healthier airflow.

Auto Restart with Memory

Automatically restores previous settings (mode, temperature, fan speed, and swing) after a power outage—no need to reset manually.

Turbo Cooling

Delivers powerful cooling in as fast as 30 seconds, quickly creating a comfortable environment.

Smart Core Self-clean

Automatically captures moisture from the air to deeply clean the evaporator. This not only delivers cleaner airflow but also ensures long-lasting, powerful operation of the core.

FAC24FECB5CCA1TH/56

Specifications

Classification

Air conditioning: Split air conditioning

Sustainable

Charged Volume(g): 1230

Technical Specification

Voltage: 220-240 V

Frequency: 50Hz

Type: 1

Cooling T1

Power Input(W): 1472

Running Current(A): 8.1

EER(W/W): 3.6

EER(Btu/h/W): 12.29

Capacity(Btu/h): 22300

Capacity(W/W): 6536

Indoor Unit

Sound Levels(S/H/M/L/SL)(dB(A)):

51/45/41/36/35, 51/45/41/36/35

Air Circulation(S/H/M/L/SL)(m³/h):

1400/1100/1050/850/800,

1400/1100/1050/850/800

Net Dimension(WxHxD)(mm): 1080X339X251

Package Dimension(WxHxD)(mm):

1156x422x348

Net/Gross Weight(kg): 16.0/19.0

Cooling T3

Capacity(W): 5774

Capacity(Btu/h): 19700

Power Input(W): 2212

Running Current(A): 9.7

EER(W/W): 2.61

EER(Btu/h/W): 8.91

Outdoor Unit

Sound Levels(H)(dB(A)): 56

Net Dimension(WxHxD)(mm): 983X700X405

Package Dimension(WxHxD)(mm):

1040X760X452

Net/Gross Weight(kg): 41.0/46.0

Piping Connection

Liquid(mm(inch)): ϕ 6.35(1/4)

Gas(mm(inch)): ϕ 15.88(5/8)

Chargeless Pipe Length

Chargeless Pipe Length(m): 5

Maximum Pipe Length

Maximum Pipe Length(m): 25

Maximum elevation Length

Maximum elevation Length(m): 10

