

PHILIPS



Smart door lock

6000 Series

Narrow body lever-style smart

Dual-sided fingerprint

32mm* narrow profile

Works with Home Access App*



DDL611LKTKB

Dual-sided fingerprint lock

Double security for every family member

Enjoy daily safe entry with the dual fingerprint lock! DDL611-18HBS has fingerprint sensors on both sides, ensuring only authorized access. This prevents suspicious individuals from reaching in. Choose DDL611-18HBS for peace of mind!

Crafted with precision, built with care

- Designed for narrow-frame doors

Smart life 'locked' with excellence

- Stay informed about your doorstep while away
- Convenient and secure access
- Tailored to meet all visitor entry needs

Secure protection, smart embedded

- Instant alerts via App
- Say goodbye to the security concerns

Highlights

32mm narrow profile

The DDL611-18HBS features a 32mm narrow profile, compatible with narrow-frame doors ranging from 25-70 mm* thick. It works seamlessly with various door types, including aluminum, thermal break aluminum, sliding, and courtyard gates. Whether for home or business, the DDL611-18HBS is the ideal choice!

Works with Home Access App*

The DDL611-18HBS works with the Home Access App, allowing you to connect to the network via a gateway. You can easily check lock operation records, doorbell notifications, and entry logs on the app anytime. Anomaly alerts will be sent as pop-up notifications, keeping you informed about your doorstep's status and providing peace of mind.

Versatile unlocking options

The DDL611-18HBS outside assembly supports four unlocking methods: fingerprint, PIN code, key tag, and mechanical key. The inside assembly offers three options: fingerprint, smart key, and mechanical key. Once a fingerprint is registered, it can be seamlessly used on both outside and inside assemblies, ensuring your access is both convenient and secure.

Custom access control PIN*

After connecting to the gateway and binding the app, the DDL611-18HBS easily meets the entry needs of different visitors. You can customize a range of temporary PIN codes, including one-time codes* valid for 6 hours, recurring codes*, or time-limited codes*. Share these temporary PIN codes remotely for convenient and secure access for your guests!

Duress unlock

In emergency situations, using a pre-set duress unlock method (fingerprint or PIN code) will trigger the lock to instantly send a duress alert notification to the administrator's app and the apps of authorized shared device users. The app will show pop-up alerts to provide security warnings, helping to enhance household safety.

Real-time push alerts

The DDL611-18HBS features multiple alert functions, including tamper alerts, system locking, and low battery notifications. In the event of an anomaly, alert information will be instantly pushed to the app, providing comprehensive home security and peace of mind.

Specifications

Design & Appearance

Color: Sky grey

Handle: Lever handle

Main Material: Aluminium alloy

Fingerprint Sensor: Semiconductor

Access Solution

Fingerprint

Password/PIN Code

Card/Key Tag

Mechanical Key

Lock Capacity

Fingerprint: Up to 100 (Master fingerprint incl.)

Card/Key Tag: Up to 100

Master PIN Code: 1

User PIN codes: Up to 20 (One-time codes and master PIN incl.)

Power Specification

Power Supply: 4 AAA batteries

Battery Type: Alkaline Batteries

Time of Use: 6 months*

Maximum Batteries Capacity: 8 batteries

Installation

Door Thickness: 25-70 mm, Other range*

Door Opening Direction: Right inward opening, Right outward opening, Left inward opening, Left outward opening



* 32mm: data based on actual measurements, with a tolerance of ± 2 mm.
 * Home Access App: DDL611-18HBS works with Home Access App.
 * 25-70mm: The included installation kit is suitable for doors with a thickness of 25-70mm. For doors outside this range, please consult an authorized dealer or customer care center for compatible products.
 * Access control PIN: A general term for various temporary PIN solutions, including one-time codes, recurring codes, and time-limited codes.
 * One-time codes: a maximum of 10 unique time-limited one-time codes can be generated within 1 hour.
 * Recurring codes: codes that can be reused at specific times each week.
 * Time-limited codes: codes set to be valid within a specific duration.
 * 6 months: this is internal test data; actual battery life may vary with usage frequency.
 * Other range: the included installation kit is suitable for doors with the mentioned thickness. For doors outside this range, please contact authorized consumer care centers or designated offline dealers.