

PHILIPS

True wireless headphones

45 hours play time

Noise Canceling Pro

6-mic technology

Detailed, natural sound

TAT7000BK



Great sound in any language

Business or pleasure, travel gets a whole lot easier with the true wireless earbuds that can help you connect. With our app and adaptive noise cancellation, you'll hear more—and say more—wherever you go.

True wireless earbuds

- Superb hi-res sound wherever you go
- Immerse freely with Adaptive Noise Canceling
- 6-mic technology. Clearer calls, even in crowded places

The perfect travel companion

- Stable Bluetooth® multipoint connection and Auracast™
- Up to 45 hours play time
- Comfy, sweat-resistant, customizable
- IPX4, earbud controls, three sizes of silicone ear tips

Seamlessly brilliant

- Quick charge for 15 minutes and get an extra 4 hours
- Philips Headphones app. Custom control
- Warm, detailed, natural. Philips sound signature
- GRS-certified recycled plastic. Responsible packaging

Highlights

Great sound

The LDAC codec is supported so you can get the most out of hi-res streaming, and Dynamic Bass brings you full, rich bass even at low volumes.

You can also turn on Spatial Audio in our companion app to enjoy a subtle surround-sound effect for music or movies. Plus, the in-app equalizer lets you adjust the bass, treble, and voice to your liking.

Noise Canceling Pro

Adaptive noise cancellation automatically reacts to your surroundings to suppress external noise, including wind, in real time. To hear what's going on around you, simply tap an earbud to activate Awareness Mode. Or activate Quick Awareness to enhance voices and have a conversation without removing an earbud.

6-mic technology

If you're on a call, our six-mic setup and a noise-reduction algorithm will combine to pick up the sound of your voice and quiet background noise. Even if you're in a busy cafe, your voice will come

through clearly, and the person you're speaking to won't need to listen to all the other conversations going on around you as well!

Bluetooth® 6.0, Auracast™

Bluetooth® 6.0 ensures a fast, steady connection, and support for Auracast™ lets you listen to public broadcasts on your travels. You can connect to two Bluetooth® devices at once and manage connected devices via our app—plus Microsoft Swift Pair makes life easy for Windows users.

45 hours play time (9 + 36)

With noise canceling off, you get 9 hours play time from a full charge and an extra 36 hours from the pocket-sized charging case (with noise canceling on, you get 6 hours and an extra 24 from the case). For a quick boost, 15 minutes in the case gives you an extra 4 hours. The case can be charged via the USB-C (not included in the packaging).

Philips Headphones app

Our handy companion app is packed with features for your earbuds. Use the app to control noise canceling and wind-noise reduction,

manage connected devices, tweak the bass, treble, and voice frequencies, get the latest firmware—and more.

IPX4 and comfy in-ear fit

An IPX4 rating means these buds can handle the moisture if you sweat, and a little light rain won't bother them either. You get three sizes of silicone ear tips for the perfect fit, and you can customize how the earbud touch controls are set up via the Philips Headphones companion app.

Philips sound signature

The custom drivers in these headphones are tuned to Philips sound signature, which brings you warm, detailed sound with rich bass. Whatever you're listening to, you'll love what you hear.

Recycled materials

We use post-consumer recycled plastics in our products, and our packaging is made from FSC-certified recycled cardboard with inserts printed on recycled paper.

Specifications

Sound

Frequency range: 20 - 40,000 Hz
Speaker diameter: 10 mm
Impedance: 16 Ohm
Maximum power input: 5 mW
Sensitivity: 112 dB (1kHz, 1mW)
Driver type: Dynamic
Hi-Res Audio

Connectivity

Bluetooth version: 6.0
Bluetooth profiles: A2DP, AVRCP, HFP
Maximum range: Up to 10 m
Multipoint connection
Supported codec: SBC, LDAC, LC3

Outer Carton

Length: 26.10 cm
Number of consumer packagings: 24
Width: 22.30 cm
Gross weight: 3.12 kg
Height: 21.50 cm
GTIN: 1 48 95229 16024 5
Nett weight: 1.76 kg
Tare weight: 1.36 kg

Convenience

Automatic power off
Volume control
Water resistance: IPX4
Philips Headphones app support
Mono mode for TWS
Firmware updates possible
Type of controls: Touch
Microsoft Swift Pair

Inner Carton

Length: 12.10 cm
Number of consumer packagings: 3
Width: 10.05 cm
Height: 9.00 cm
Nett weight: 0.22 kg
Gross weight: 0.35 kg
Tare weight: 0.13 kg
GTIN: 2 48 95229 16024 2

Power

Number of batteries: 3 pcs
Charging time: 2 hour(s)
Music play time (ANC on): 6 + 24 hour(s)
Music play time (ANC off): 9 + 36 hour(s)

Fast charging time: 15 mins for 4 hrs

Battery type(Charging case): Lithium Polymer (built-in)

Battery type(Earbud): Lithium Polymer (built-in)

Battery weight (Total): 17.8 g

Battery capacity(Case): 740 mAh

Battery capacity(Earbud): 55 mAh

Packaging dimensions

Height: 10 cm
Packaging type: Carton
Type of shelf placement: Hanging
Width: 9.7 cm
Depth: 3.8 cm
Number of products included: 1
EAN: 48 95229 16024 8
Gross weight: 0.101 kg
Nett weight: 0.073 kg
Tare weight: 0.028 kg

Accessories

Quick Start Guide
Eartips: 4 pairs (S/M/L/XL)
Charging case

Design

Color: Black
Ear coupling material: Silicone
Ear fitting: In-ear
In-ear fitting type: Silicone ear tip

Telecommunication

Microphone for call: 3 mics on each side
Wind noise reduction

Dimensions

Charging case dimension(WxDxH): 6.49 x 3.01 x 4.07 cm
Earbud dimension(WxDxH): 2.15 x 2.42 x 2.77 cm
Total weight: 0.051 kg

UPC

UPC: 8 40063 20628 1

ANC features

ANC technology: Hybrid, ANC Pro
Awareness mode
Microphone for ANC: 4 mic
ANC (Active Noise Canceling)

Voice assistant

Voice assistant compatible: Apple Siri, Google Assistant

Voice assistant activation: Multi-Function touch
Voice assistant support

Sustainability

Plastic shell: contains 64% GRS certified Recycled post-consumer Polycarbonate TE-00132492

