

# PHILIPS



## LED Display

### Signage Solutions

44"

### Direct View LED



44BDL8128L

## Limitless

### Bezel-free LED display wall.

Fill their imagination. Create seamless displays. With an L-Line Professional LED Display Wall, the possibilities are endless. The bezel-free design, wide viewing angle, and breathtaking brightness ensure authoritative imaging. At any size.

#### **Immersive viewing. Versatile LED solution.**

- Perfect clarity. From broadcast studio to control room
- Ultra-high refresh rate. Smooth, judder-free images
- Ultra-thin pixel pitch of 2.8 mm. Beautiful at any size
- Create bezel-free video walls of any shape or size

#### **Effortless setup. Reliable performance.**

- Join multiple cabinets to achieve higher resolution
- Built-in rear cable cover. Easy cable management
- Front-access LED modules. Easy maintenance and servicing
- High performance gold-wire LEDs
- Slim, lightweight die-cast aluminum cabinet (56 mm deep)

#### **Spectacular picture. Endless possibilities.**

- Ultra-high brightness even at wide viewing angles
- Zero bezel. Create seamless display screens
- LED display. Superb image quality. Perfect uniformity

## Highlights

### **LED display. Superb image**

Create bezel-free video walls of any shape, size, or resolution. The modular design of Philips Professional LED cabinets means you can adapt to any space. Build vast, immersive installations or assemble intriguing patterns. Easily create video walls that flow seamlessly around doorways and other openings.

### **Create bezel-free video walls**

Simply connect multiple LED display cabinets to create the resolution you want-whether it's 4K, 8K, or even higher. Compared to LCD screens, LED displays boast higher refresh rates that

enable smoother images. Whatever the application, you'll thrill them with crystal-clear picture quality.

### **High performance gold-wire LED**

Philips Professional LED Displays use high-performance gold-wire LEDs, which are energy-efficient and cost-effective. Light is brighter, and the LEDs last longer.

### **Front-access LED modules.**

Internal electronics are easy to access for servicing or maintenance. Each of the eight LED modules in a cabinet can be removed using a dedicated magnetic JIG tool, which lifts the module out from the front.

### **Built-in rear cable cover.**

Your Philips Professional LED Display features built-in rear cable covers to keep power and data cables tidy. Display cabinets can also be daisy-chained, for both power and data. Allowing you to minimize clutter, speed up installation.

# Specifications

## Picture/Display

Aspect ratio: 1:2  
Brightness Uniformity:  $\geq 97\%$   
Brightness after calibration: 800 nits  
Brightness before calibration: 1000 nits  
Calibration(brightness/color): Supported  
Color temperature adjust range: 4000~9500 K  
(by software)  
Color temperature default: 6500 $\pm$ 500 K  
Contrast ratio (typical):  $\geq 3000:1$   
Viewing angle (horizontal): 140 degree  
Viewing angle (vertical): 140 degree  
Picture enhancement: Dynamic contrast enhancement, Wide color gamut display  
Placement: Portrait  
Frame frequency (Hz): 50 & 60  
Refresh rate(Hz): 1200~1920  
Usage: 24/7 Hrs, Indoor

## Convenience

Ease of installation: Guide pins, Light weight, Locking mechanism for cabinet  
Power loop through: For 230V environments: 6 cabinets or less, for 110V environments: 3 cabinets or less  
Signal control loop through: RJ45

## Power

Consumption (Typical):  $\leq 87$  W  
BTU Value m2: 1,773 BTU/m2  
Cabinet Max Power consumption: 260 W  
Input voltage: AC200~240V/AC100-120V (50-60Hz)

## Operating conditions

Temperature range (operation): -20~45 °C  
Temperature range (storage): -20 ~ 50 °C  
Humidity range (operation)[RH]: 10~80%  
Humidity range (storage) [RH]: 10~85%

## Cabinet

Cabinet area (m2): 0.5  
Cabinet pixels ( Dot ): 61,952  
Cabinet resolution (W x H): 176x352  
Cabinet size (mm): 500x1000x86  
Data connector: RJ45  
Power connector: In/Out(C14/C13)  
Receiving card quantity: 1 pcs  
Receiving card spec.: A55 / A55 Plus  
Receiving card brand: Novastar  
Weight (KG): 15.6 kg  
Cabinet diagonal (inch): 44  
Cabinet construction: Aluminum+Steel

## Module

LED type: SMD 2121 Gold wire  
Pixel constitution: 1R1G1B  
LED lifetime(Hrs): 100,000  
Module resolution (WxH pixels): 88x88  
Module size (WxHxD in mm): 250\*250\*19.1  
Pixel pitch (mm): 2.84

## Accessories

Common connecting piece: 3 pcs  
LAN cable (RJ45, CAT-5): 1 pcs (130cm)  
QSG: 1 pcs  
Screw bolt: 4 pcs (M10\*70) (Inner Hexagon Screw)  
Power loop through cable: 1 pcs

## Miscellaneous

Warranty: 3 year  
Regulatory approvals: FCC SDOC, Part 15, EMC Class A, EN55032, EN55035, EN61000-3-2, EN61000-3-3, IEC/UL60950, IEC/UL62368, IEC62471, RoHS

