

PHILIPS



Push-pull smart door lock

7000 Series

Fingerprint unlock

App remote unlock

Temporary PIN distribution

Real-time push alerts



DDL720LCAKW

Smart remote connection

Keeping your home secure anywhere

Real-time smart remote control – security in your hands! Connect the Philips DDL720-5HWS to the Home Access App to view lock activity and receive alerts anytime, keeping your home fully under control.

Smart life "locked" with excellence

- Swift and stable Recognition
- Stay updated on your door activity while away
- No waiting for visitors
- Flexible access for all visitors

Secure protection, smart embedded

- Instant alerts for mortise abnormalities
- No more security worries

Easy life goes beyond this

- Ideal for the whole family
- One turn, instant unlock

Highlights

Semiconductor fingerprint

The DDL720-5HWS boasts a reliable semiconductor fingerprint sensor with a recognition speed of $\leq 0.5s^*$. Once recognized, the latch automatically retracts—no additional action needed. Simply push the door for a fast, effortless entry.

Works with Home Access App

The DDL720-5HWS works with the Home Access App. Once connected to the network, you can check the lock's activity log, doorbell messages, and unlock records anytime, anywhere. Instant alerts notify you of any abnormal activity, keeping you informed of your door's status for complete peace of mind.

Remote unlock

As soon as a visitor rings the doorbell, the App notifies you. Tap the unlock button within 5 seconds, and the door opens remotely—letting your guest enter instantly, no waiting required.

Temporary access methods*

With the Home Access App, you can easily set various temporary access methods, such as recurring* or time-limited* schedules, and remotely share a one-time PIN valid for 30 minutes. Fingerprints, PIN codes, and key tags can all be configured for temporary use, allowing visitors to enter effortlessly without waiting.

Electronic sensor mortise

The DDL720-5HWS features a 311 mortise with a detection switch for improved security and convenience compared to regular mechanical locks. Real-time alerts for tampering, door left ajar for too long*, or latch malfunctions are triggered on your lock and sent to the app, so your home stays protected at all times.

Real-time push alerts

Home security, fully protected. The DDL720-5HWS offers multiple safety alerts—including latch abnormality detection, armed mode*, tamper detection, and system lock-out. Any abnormal events are pushed in real time to the app, ensuring your home is always secure.

6 unlocking methods

The DDL720-5HWS supports six unlocking methods: fingerprint, PIN code, App, remote control* (optional), key tag, and mechanical key, providing easy access for users of all ages, including the elderly and children.

Indoor quick-open handle

The indoor assembly features a quick-open handle. In an emergency, even if the smart lock's electronic functions fail, simply turning the handle unlocks the door, ensuring user safety and peace of mind.

Specifications

Design & Appearance

Color: Sky grey

Handle: Push-pull handle

Main Material: Aluminium alloy

Access Solution

Fingerprint

Password/PIN Code

Card/Key Tag

Mechanical Key

Mobile APP

Remote control: Optional

Lock Capacity

Fingerprint: Up to 100 (Master fingerprint incl.)

Card/Key Tag: Up to 100

Master PIN Code: 1

User PIN Code: Up to 20 (One-time codes incl.)

Power Specification

Battery Type: Li-polymer Battery

Time of Use: 3 months*

Battery Capacity: 5000 mAh

Installation

Door Thickness: 38-120 mm, Other range*

Door Opening Direction: Right inward opening, Right outward opening, Left inward opening, Left outward opening

Door Type: Wooden door, Security door

Door backset: 60 mm



* 0.5s: data based on internal testing.

* Temporary access methods: When the system is in dual verification mode, the lock does not support unlocking via temporary access methods.

* Recurring: refers to any access method (PIN, fingerprint, or key tag) that users can configure for weekly use during designated time periods.

* Time-limited: refers to any access method (PIN, fingerprint, or key tag) that users can schedule to be used during designated time periods.

* Electronic sensor mortise: a mortise with electronic detection functions that triggers alerts when it senses abnormal latch conditions.

* Door left ajar for too long: if the door is not closed within 10 seconds of unlocking, the lock will issue the alert: "Door has not closed." This function is only supported when using the included mortise equipped with electronic detection.

* Armed mode: available only with the included mechanical mortise equipped with a detection switch. It won't work with a mechanical mortise without a detection switch.

* Remote control: not included as standard; sold separately.

* 3 months: this is internal test data; actual battery life may vary with usage frequency

* Other range: the included installation kit is suitable for doors with the mentioned thickness. For doors outside this range, please contact authorized consumer care centers or designated offline dealers.