

# PHILIPS

## Open-ear true wireless earbuds

True wireless open earbuds

4-way adjustable ear hooks

Up to 36 hours play time

Bluetooth® 6.0

TAQ4000WT



## Open-ear buds. Four ways to fit.

Walks to workouts, music to podcasts, these open-ear buds sound great on the move. Adjustable ear hooks let you adapt the fit for maximum comfort, while the open-ear design lets you hear the world as well as what you're listening to.

### **True wireless earbuds. Essential comfort.**

- Philips Headphones app. Customize your experience
- Intuitive in-app equalizer and Dynamic Bass
- 4-mic technology. Clearer calls, even in crowded places
- RCS-certified recycled plastic. Responsible packaging

### **True wireless open earbuds, adjustable ear hooks**

- 4-way adjustable ear hooks for a custom open-ear fit
- Easily adjust the fit for secure all-day comfort
- Great sound for music and podcasts
- Precision air conduction drivers. Full spectrum audio

### **Your daily go-to**

- Up to 36 hours play time with charging case
- Quick charge for 10 minutes to get an extra hour
- IPX5 water resistant
- Bluetooth® multipoint connectivity and easy pairing

# Specifications

## Sound

Acoustic system: Closed  
 Frequency range: 20 - 20,000 Hz  
 Speaker diameter: 15.8 mm  
 Impedance: 16 Ohm  
 Maximum power input: 30 mW  
 Sensitivity: 128 dB (1KHz, 126mV)  
 Driver type: Dynamic

## Connectivity

Bluetooth version: 6.0  
 Bluetooth profiles: HFP, A2DP, AVRCP  
 Maximum range: Up to 10 m  
 Multipoint connection  
 Supported codec: SBC

## Outer Carton

Length: 26.50 cm  
 Number of consumer packagings: 24  
 Width: 24.30 cm  
 Gross weight: 4.08 kg  
 Height: 24.30 cm  
 GTIN: 1 48 95229 17984 1  
 Nett weight: 2.59 kg  
 Tare weight: 3.76 kg

## Convenience

Volume control: Touch control  
 Water resistance: IPX5  
 Philips Headphones app support  
 Firmware updates possible  
 Type of controls: Touch  
 LED safety lights

## Inner Carton

Length: 12.40 cm  
 Number of consumer packagings: 3  
 Width: 11.40 cm  
 Height: 10.90 cm  
 Nett weight: 0.32 kg  
 Gross weight: 0.46 kg  
 Tare weight: 0.14 kg  
 GTIN: 2 48 95229 17984 8

## Power

Number of batteries: 3 pcs  
 Music play time: 8 + 28 hour(s)  
 Charging time: 2 hour(s)  
 Fast charging time: 10 mins for an hour

Battery type(Charging case): Lithium Polymer (Built-in)

Battery type(Earbud): Lithium Polymer (Built-in)  
 Battery weight (Total): 17.3 g  
 Battery capacity(Case): 720 mAh  
 Battery capacity(Earbud): 70 mAh

## Packaging dimensions

Height: 11.7 cm  
 Packaging type: Carton  
 Type of shelf placement: Hanging  
 Width: 11.6 cm  
 Depth: 3.5 cm  
 Number of products included: 1  
 EAN: 48 95229 17984 4  
 Gross weight: 0.134 kg  
 Nett weight: 0.108 kg  
 Tare weight: 0.026 kg

## Accessories

Quick Start Guide  
 Charging case

## Design

Color: Black  
 Wearing style: Ear-hook  
 Ear fitting: Open-ear  
 In-ear fitting type: Open fit

## Telecommunication

Microphone for call: 2 mics on each side

## Voice assistant

Voice assistant compatible: Apple Siri, Google Assistant  
 Voice assistant activation: Multi-Function touch  
 Voice assistant support

## Dimensions

Earbud dimension(WxDxH): 4.45 x 4.06 x 1.28 cm  
 Charging case dimension(WxDxH): 8.52 x 5.97 x 2.81  
 Total weight: 0.074 kg

## Sustainability

Plastic shell: Plastic shell contains 69% RCS certified recycled post-consumer Polycarbonate TE-00132492

# Highlights

## Open-ear true wireless fit

No two ears are alike, so these buds give you four ways to make the fit yours. Soft, flexible hooks loop around your ears and adjust across four positions for secure all-day comfort, even with glasses on.

## Full-spectrum audio

Precision air-conduction drivers deliver natural, balanced sound into your ear canal, whichever fit you choose. Voices come through clearly for podcasts, while full-spectrum audio brings bass, mids, and highs together for music that hits just as it should.

## 36 hours play time (8 + 28)

You get 8 hours play time from a full charge, and an extra 28 hours from the case. If you need a quick boost, pop the earbuds back in the case for 10 minutes to get an extra hour. It takes 2 hours to recharge the earbuds fully, and mono mode lets you use one earbud at a time while the other one charges.

## IPX5 water resistant

With an IPX5 rating, these open-ear buds are ready for whatever your day brings. They'll handle sweaty workouts, dusty streets, muddy trails, and light rain without missing a beat.

## Bluetooth® 6.0

Compatibility with the latest Bluetooth® 6.0 devices lets you stream without annoying dips in the sound, and you can connect to two devices at once. Microsoft Swift Pair is supported too.

## 4-mic technology

These headphones boast a four-mic setup, and two of those mics plus an AI noise-reduction algorithm combine to bring you super-clear calls. Even if you're in a busy cafe, your voice will come through clearly and the person you're speaking to won't be distracted by what's going on around you.

## Philips Headphones app

Feel like your music's missing something? Our companion app features AI Neural EQ, an intuitive equalizer that lets you tweak the sound and explore different EQ settings using your fingertips. You can also use the app to activate Dynamic Bass, manage connected devices, update firmware, and more.

## Recycled materials

We use post-consumer recycled plastics in our products, and our packaging is made from FSC-certified recycled cardboard with inserts printed on recycled paper.

