

Register your Click & Style on

www.philips.com/myclickandstyle

S738, S728, S720





PHILIPS



- UK** Shave with a circular motion.
DK Foretag barbering med en cirkelbevægelse.
DE Rasieren Sie sich mit kreisenden Bewegungen.
EL Ξυρίστε με κυκλικές κυνήσεις.
ES Aféitese realizando movimientos circulares.
FI Aja ihokarvat pyörivin liikkein.
FR Rasez-vous en effectuant des mouvements circulaires.
IT Effettuate la rasatura con movimenti circolari.
NL Scheer met een draaiende beweging.
NO Barber med en sirkulær bevegelse.
PT Barbear com um movimento circular.
SE Rakning med cirkelrörelser.
TR Dairesel hareketlerle tıraş olun.
 قم بالحلاقة بحركة دائيرية. **AR**
 با حركة دائيرية اصلاح کنید. **FA**

- UK** Apply gentle pressure: not too hard and not too soft.
DK Tryk let: ikke for hårdt og ikke for blødt.
DE Üben Sie leichten Druck aus: nicht zu fest und nicht zu sanft.
EL Ασκήστε ελαφριά πίεση: ούτε πολύ δυνατά ούτε πολύ απαλά.
ES Ejera presión levemente: ni demasiado fuerte ni demasiado suave.
FI Paina hellävaroen: ei liian kovaa eikä liian pehmeäästi.
FR Exercez une légère pression : ni trop forte, ni trop faible.
IT Applicate una pressione delicata, né troppo forte, né troppo lieve.
NL Oefen milde druk uit: niet te hard en niet te zacht.
NO Ha et lett trykk: ikke for hardt og ikke for mykt.
PT Aplicar um pouco de pressão: sem exercer demasiada pressão nem pressão insuficiente.
SE Tryck försiktigt: inte för hårt och inte för lätt.
TR Çok sert ve çok hafif olmamak kaydıyla hafif baskın uygulayın.
 استخدم الضغط الخفيف: ليس بقوه مبالغة ولا نعومة مبالغة. **AR**
 آرام فشار وارد کنید: نه بیش زیاد و نه بیش از حد کم. **FA**

- UK** Shave often or trim long hairs before shaving.
DK Barber dig ofte, eller trim lange hår inden barberingen.
DE Rasieren Sie sich regelmäßig, oder trimmen Sie lange Haare vor der Rasur.
EL Αν δεν ξυρίζεστε συχνά, να τριμάρετε τις μακριές τρίχες πριν ξυρίστετε.
ES Aféitese con frecuencia o recorte los pelos largos antes de afeitarse.
FI Aja ihokarvat usein tai trimmaa pitkät ihokarvat ennen ajamista.
FR Rasez-vous fréquemment ou tondez les poils longs avant de vous raser.
IT Radetevi spesso oppure rifinite i peli più lunghi prima di effettuare la rasatura.
NL Scheer regelmatig of trim lange haren voordat u gaat scheren.
NO Barber deg ofte, eller trim lange hår før barbering.
PT Barbeie-se regularmente ou apare os pêlos compridos antes de se barbear.
SE Raka dig ofta eller trimma långa hårstrån innan du rakar dig.
TR Sık tıraş olun veya uzun killan tıraş öncesi düzeltin.
 قم بالحلاقة بصورة كبيرة أو قم بتهذيب الشعيرات الطويلة قبل الحلاقة. **AR**
FA اغلب اوقات اصلاح کنید یا قبل از اصلاح موهای بلند را کوتاه کنید.




S738
S728



S738
S720



S738






1








2








www.philips.com/support







S738
S720




















S738
S720




























1M





S728 S738









TT2000


1




2




3



4




5







1




2





3




4




5



6



7





FSC

4222.002.5734.3

www.philips.com