


PHILIPS

Dispenser

ADD4954



User Manual 1-6
Petunjuk Penggunaan 7-12


Content

1	Main technical specification	1
2	Product overview	2
3	Instruction	3
4	Precautions	3
5	Cleaning and maintenance	5
6	Trouble shooting	5
7	Guarantee and Service	6
8	Packing list	6

1 Main technical specification


Model	ADD4954
Rated voltage	220V-240V~
Rated frequency	50Hz
Heating power	170W/350W
Cooling power	85W
Hot water	≥90°C, 3.8L/h with high power, 1.8L/h with low power
Cold water	≤10°C, 2L/h
Environmental temp.	T
Coolant	R134a, 38g
Relative humidity	≤90%
Protection of anti-electric shock	I

2 Product overview



- ① Bottle Seat
- ② Power Switch
- ③ Indicator Lights
- ④ Information Plate
- ⑤ Child Safety Lock
- ⑥ Cold Water Faucet

- ⑦ Ambient Water Faucet
- ⑧ Hot Water Faucet
- ⑨ Drip Tray
- ⑩ Electric Power Cord
- ⑪ Drain Plug
- ⑫ Lower Cabinet



At the back of the dispenser there is a black switch which controls the heating power. You may press it to switch between high power, low power and OFF.

Every time when you plug in the water dispenser again, it will need some time for getting hot and cold water.

Turn the black heating switch to 'I', please wait for around 30 minutes for hot water;

Turn the black heating switch to 'II', please wait for around 15 minutes for hot water;

Turn the green cooling switch to 'ON', please wait for around an hour for cold water.

3 Instruction

- Unpack the water dispenser. Place the dispenser indoors, on a flat surface and at a distance no less than 15 cm from the back wall.
- Insert the bottle vertically on the seat
- Press the red hot water faucet until water flows out.
- Insert the power plug to the wall socket.
- Turn on the power switch on the back of the unit. The cooling or heating feature will start running. The indicator light will be on when heating or cooling function is working. Do not touch both switches during the time.
- Enjoy the hot or cold water you need.
- If you are not going to use hot water, turn the black heating switch to 'O'; if you are not going to use cold water, turn the green cooling switch to "OFF" to conserve energy.

4 Precautions

- The drain plug on the back of the unit may become loose during shipping. Fasten the drain plug tightly before you start to operate the unit. If the drain plug is loose, the unit may leak and cause floor damage.

- Make sure to have poured water from the hot water faucet before plugging and switching the appliance ON to heat. If the dispenser is turned ON with an empty water tank, it can be damaged.
- When you are ready to move the water dispenser, do not tilt more than 45° to avoid damage to the compressor.
- Keep this appliance away from high temperatures and in a dry and ventilated place. Never install it in the open air or under rain or direct sunlight.
- Children should not use the red hot water tap.
- If the appliance is not going to be used for a long period of time, unplug it and drain all water in its interior.
- Before the first use and after a long period of not using it, the water tank and water pipes should be cleaned well. If possible, they should be disinfected and disinfect, and the first heated water must be discarded (switch the heating switch to 'O' while draining the system).
- Wash and disinfect the system every 3–6 months with a suitable cleaner and according to its instructions for use.
- Do not pull out the cable to unplug. Do not turn on and off the appliance by connecting it and disconnecting it from the source of electricity.
- Do not clean the outside of the appliance with water in case of electric shock. Clean it with a soft cloth.
- If you are not using the appliance for a long period of time or during the night, you can turn it off to save energy.
- Do not attempt to change the power cord by yourself if it has any damage. Contact the aftersales personnel for support.
- If the power cable suffers any damage, contact the aftersales personnel for support.
- The equipment must be installed keeping easy access to the electrical plug.
- WARNING – to avoid the risks of an unstable installation, the equipment must be installed following its instruction.
- WARNING – keep the ventilation openings at the back of the appliance uncovered and unobstructed.
- NOTICE – do not damage the refrigerant circuit.
- The environmental temperature for this appliance should be between 18° C and 38 ° C.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and use maintenance shall not be made by children without supervision.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

5 Cleaning and maintenance

- To avoid accidents, turn off and unplug the water dispenser from the outlet before cleaning.
- A soft damp cloth may be used to clean the surface of the water dispenser. When necessary, a mild detergent may be used. DO NOT use corrosive chemical solvents to clean the unit, as this may damage the surface of the water dispenser.
- DO NOT pour water on the exterior of the unit to avoid getting the internal electrical system wet . DO NOT immerse the unit in water when cleaning.
- The water bottle cap, hose, and drip tray may be washed in a dishwasher (top rack only).
- Keep the water dispenser 6 inches (15cm) away from the wall so it can work properly. Make certain all ventilation openings are clear of obstruction.
- Do not damage the heating or cooling system, paying particular attention to the black condenser or heating radiator on the back of the water dispenser.
- If you will not use the water dispenser for a long period of time, please unplug the power cord and drain the water dispenser. Drain the water from all faucets, then remove the drain plug on back and allow it to drain. Make certain the drain plug is fastened tightly when finished.

6 Trouble shooting

Trouble	Possible causes	Solutions
Lights do not lit	1.Appliance is not connected to the electrical system 2.The switch is not on	1.Make sure that the switch is ON and the plug is connected 2.Turn the switch into on
Leaking	1.The water tank is broken 2.The water pipe is broken 3.The faucet is damaged	Contact aftersales personnel for support
Not heating	1.Heating switch is damaged or makes not contact 2.The heating tank is broken 3.The electrical connection is loose	Contact aftersales personnel for support
Not cooling	1.Cooling switch is damaged or makes no contact 2.The electrical connection is loose	Contact aftersales personnel for support

7 Guarantee and Service

This product includes a two-year warranty for the dispenser and five-year warranty for compressor from the date of purchase. For more details about warranty conditions, please refer to the warranty information in the box. If you need more information, please visit: www.Philips.com.

Within the warranty period, you will receive free warranty service for any damage caused by the manufacturing process or components under normal operation confirmed by our maintenance service.

The warranty service does not include frequent replaced consumable components (water purifier filter, pitcher filter, granular activated carbon, ion exchange resin, hollow fiber membrane, etc.), auxiliary devices, transportation fee and door-to-door service.

Please show the proof of purchase to the service personnel during maintenance.

You cannot receive free warranty service under the following conditions:

1. Damage by improper operation, such as improper components connection, improper installation, deprived of manual use, misoperation.
2. Negligence and damage because of transportation or other accident.
3. Maintenance and modification without approval.
4. Other damage caused by force majeure (such as natural disaster, abnormal voltage, etc.).
5. Damage caused by general use outside home (e.g. industrial and commercial use).
6. Aging, wear and tear caused by normal operation of the product without affecting normal operation of the product.

This statement serves as a publicity for free maintenance within the specified time limit and conditions, and does not limit the legal rights of consumers.

8 Packing list

Water dispenser	1x
User Manual	1x

Please keep this user manual for future reference.


Daftar Isi

1	Spesifikasi teknis	7	7	Jaminan dan layanan	12
2	Bagian-bagian produk	8	8	Isi dalam kemasan	12
3	Petunjuk pengoperasian	8			
4	Tindakan pencegahan	9			
5	Pembersihan dan perawatan	11			
6	Pemecahan masalah	11			


1 Spesifikasi teknis

Model	ADD4954
Tegangan	220V-240V~
Frekuensi	50Hz
Daya pemanas	170W/350W
Daya pendingin	85W
Air panas	≥90°C, Daya tinggi : 3.8L/h Daya rendah : 1.8L/h
Air dingin	≤10°C, 2L/h
Kelas iklim	T
Cairan pendingin	R134a, 38g
Kelembaban relatif	≤90%
Kelas pengaman terhadap daya kejut listrik	I

2 Bagian-bagian produk



- | | |
|---------------------------------------|--------------------------|
| ① Dudukan galon | ⑦ Tombol kran air normal |
| ② Saklar daya | ⑧ Tombol kran air panas |
| ③ Lampu indikator | ⑨ Baki tetesan air |
| ④ Label informasi | ⑩ Kabel daya listrik |
| ⑤ Kunci pengaman anak untuk air panas | ⑪ Saluran pembuangan |
| ⑥ Tombol kran air dingin | ⑫ Kabinet bawah |



Di belakang dispenser ada saklar hitam yang mengontrol daya pemanas.

Anda dapat menekannya untuk beralih antara daya tinggi, daya rendah dan OFF.

Setiap kali Anda menghidupkan dispenser air lagi, akan perlu waktu untuk menjadikan air panas dan dingin.

Atur saklar pemanas hitam ke 'I', tunggu sekitar 30 menit untuk air panas;

Atur saklar pemanas hitam ke 'II', tunggu sekitar 15 menit untuk air panas;

Atur saklar pendingin hijau ke "ON", tunggu sekitar satu jam untuk air dingin.

3 Petunjuk pengoperasian

- Buka kemasan unit dispenser. Tempatkan di dalam ruangan, pada permukaan yang rata dan pada jarak tidak kurang dari 15 cm dari dinding belakang.
- Masukkan galon air secara vertikal pada dudukan galon.
- Tekan tombol kran air panas merah hingga air keluar.
- Masukkan steker kabel daya listrik ke stopkontak.
- Nyalakan saklar daya di bagian belakang unit. Fitur pendingin atau pemanas akan mulai berjalan.
- Lampu indikator menyala ketika fungsi pemanas atau pendingin bekerja. Jangan menyentuh kedua saklar selama fungsi ini bekerja.
- Nikmati air panas atau dingin yang Anda butuhkan.
- Jika Anda tidak menggunakan air panas, atur saklar pemanas hitam ke "O" jika Anda tidak menggunakan air dingin, atur saklar pendingin hijau ke "OFF" untuk menghemat energi listrik.

4 Precautions

- Tutup saluran pembuangan di bagian belakang unit mungkin longgar saat pengiriman. Kencangkan tutup saluran pembuangan hingga ketat sebelum Anda mulai mengoperasikan unit. Jika tutup saluran pembuangan longgar, air dalam unit dapat bocor keluar dan menyebabkan lantai basah..

- Pastikan Anda telah menuangkan air dari keran air panas sebelum mencolokkan steker kabel listrik ke stopkontak dan menghidupkan unit ke posisi panas. Jika dispenser dihidupkan dengan tangki air kosong, beresiko rusaknya unit.
- Jika Anda memindahkan penempatan unit dispenser ini, jangan miringkan lebih dari 45o untuk menghindari kerusakan pada kompresor.
- Jauhkan penempatan unit ini dari suhu tinggi, tempatkan di tempat yang kering dan berventilasi. Jangan menempatkannya di udara terbuka atau di yang terkena air hujan atau sinar matahari langsung.
- Pastikan anak-anak tidak menggunakan kran air panas warna merah.
- Jika unit tidak digunakan untuk jangka waktu lama, cabut steker kabel listrik dari stopkontak dan buang semua air di bagian dalamnya.
- Sebelum penggunaan pertama kali dan setelah lama tidak menggunakannya, tangki air dan pipa air harus dibersihkan dengan baik. Jika mungkin, didesinfeksi, dan air panas pertama harus dibuang (alihkan saklar pemanas ke 'O' saat mengerjakan sistem).
- Cuci dan disinfeksi sistem setiap 3-6 bulan dengan pembersih yang sesuai dan sesuai dengan petunjuk penggunaannya.
- Jangan mencabut bagian kabelnya saat mencabut kabel listrik dari stopkontak, pegang dan cabut bagian stekernya. Jangan menyalakan dan mematikan unit dengan menghubungkan dan melepaskan kabel listrik dari stopkontak sumber listrik.
- Jangan membersihkan bagian luar unit dengan air karena beresiko terkena sengatan listrik. Bersihkan dengan kain lembut.
- Jika Anda tidak menggunakan unit untuk jangka waktu lama atau pada malam hari, Anda dapat mematikannya untuk menghemat energi listrik.
- Jangan mencoba mengganti kabel listrik sendiri jika ada kerusakan. Hubungi personel servis untuk mendapatkan bantuan.
- Jika kabel daya listrik mengalami kerusakan, hubungi personel servis untuk mendapatkan bantuan.
- Tempatkan unit dispenser di tempat yang mudah jangkauannya ke sumber listrik atau dekat dengan stopkontak rumah.
- PERINGATAN – untuk menghindari resiko instalasi yang tidak stabil, unit harus dipasang mengikuti petunjuk.
- PERINGATAN – pastikan lubang ventilasi di bagian belakang unit dispenser tetap terbuka dan tidak terhalang.
- PEMBERITAHUAN – jangan merusak sirkuit pendingin.
- Suhu lingkungan untuk alat ini antara 18 ° C sampai 38 ° C.
- Unit dispenser ini dapat digunakan oleh anak-anak berusia 8 tahun ke atas. Untuk orang-orang dengan kemampuan fisik, sensorik atau mental yang berkurang atau kurangnya pengalaman dan pengetahuan, perlu diberi petunjuk agar dapat menggunakan unit dispenser dengan benar dan aman, serta memahami bahaya yang dapat ditimbulkannya. Anak-anak tidak boleh bermain-main dengan unit dispenser ini. Pembersihan dan pemeliharaan tidak boleh dilakukan oleh anak-anak tanpa pengawasan.
- Jangan menyimpan bahan mudah meledak seperti kaleng aerosol dengan propelan yang mudah terbakar di unit dispenser ini.

5 Pembersihan dan perawatan

- Untuk menghindari kecelakaan, matikan dan cabut steker kabel listrik dispenser dari stopkontak sebelum membersihkan.
- Kain lembab yang lembut dapat digunakan untuk membersihkan permukaan unit. Bila perlu, deterjen ringan dapat digunakan. JANGAN gunakan pelarut kimia korosif untuk membersihkan unit, karena dapat merusak permukaan unit.
- JANGAN tuangkan air ke bagian luar unit untuk menghindari sistem listrik bagian dalam unit basah
- JANGAN celupkan unit ke dalam air saat membersihkan.
- Tutup galon air, slang, dan baki tetes dapat dicuci di mesin pencuci piring (hanya rak atas).
- Beri jarak 15 cm antara unit dan dinding agar unit dapat bekerja dengan baik. Pastikan semua lubang ventilasi tidak terhalang.
- Jangan merusak sistem pemanas atau pendingin, beri perhatian pada kondensor warna hitam atau radiator pemanas di bagian belakang unit.
- Jika Anda tidak menggunakan dispenser untuk waktu yang lama, cabut steker kabel listrik dari stopkontak dan bersihkan dispenser. Kuras air, keluarkan dari semua kran, lalu lepaskan tutup saluran pembuangan di bagian belakang dan biarkan air mengalir. Pastikan tutup saluran pembuangan terpasang kencang saat selesai pengurasan.

6 Pemecahan masalah

Masalah	Possible causes	Solutions
Lampu indikator tidak menyala	1.Unit tidak terhubung ke sistem listrik 2.Saklar tidak aktif	1.Pastikan saklar HIDUP dan steker kabel listrik terhubung ke stopkontak 2.Turn the switch into on
Bocor	1.Tangki air rusak 2.Pipa air rusak 3.Kran rusak	Hubungi personel servis untuk mendapatkan bantuan
Pemanas tidak berfungsi	1.Saklar pemanas rusak atau tidak bersentuhan 2.Tangki pemanas rusak 3.Sambungan listrik kendur	Hubungi personel servis untuk mendapatkan bantuan
Pendingin tidak berfungsi	1.Saklar pendingin rusak atau tidak terjadi kontak 2.Sambungan listrik longgar	Hubungi personel servis untuk mendapatkan bantuan

7 Jaminan dan layanan

Produk ini mencakup garansi dua tahun dari tanggal pembelian. Untuk detail lebih lanjut tentang ketentuan garansi, silakan merujuk ke informasi garansi di dalam kemasan. Jika Anda memerlukan informasi lebih lanjut, silakan kunjungi: www.Philips.com.

Dalam satu tahun sejak tanggal pembelian, Anda akan menerima layanan garansi gratis untuk segala kerusakan yang disebabkan oleh proses pembuatan atau komponen dalam operasi normal yang dikonfirmasi oleh servis center kami.

Layanan garansi tidak termasuk komponen habis pakai yang sering diganti (filter pemurni air, filter pitcher, karbon aktif granular, resin penukar ion, membran serat berlubang, dll.), Perangkat tambahan, biaya transportasi, dan layanan door-to-door. Tunjukkan bukti pembelian kepada petugas servis selama perawatan.

Anda tidak dapat menerima layanan garansi gratis dalam kondisi berikut:

1. Kerusakan oleh pengoperasian yang tidak benar, seperti koneksi komponen yang tidak tepat, pemasangan yang tidak benar, kehilangan petunjuk penggunaan, salah pengoperasian.
2. Kelalaian dan kerusakan karena transportasi atau kecelakaan lainnya.
3. Pemeliharaan dan modifikasi tanpa persetujuan.
4. Kerusakan lain yang disebabkan oleh force majeure (seperti bencana alam, tegangan listrik tidak normal, dll.).
5. Kerusakan yang disebabkan oleh penggunaan umum di luar rumah (mis. Penggunaan dalam industri dan komersial).
6. Penuaan, keausan yang disebabkan oleh pengoperasian normal produk tanpa mempengaruhi operasi normal produk.

Pernyataan ini berguna sebagai informasi untuk mendapatkan pemeliharaan gratis dalam batas waktu dan ketentuan yang ditetapkan dan tidak membatasi hak hukum konsumen.

8 Isi dalam kemasan

Unit Dispenser	1x
Petunjuk penggunaan	1x

Simpan Petunjuk Penggunaan untuk referensi di masa mendatang.



Register your product and learn more in the website link below:
www.philips.com/welcome

Specifications are subject to change without notice

© 2019 AquaShield

All rights reserved.

The Philips trademark and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. used under license.

This product has been manufactured by and is sold under the responsibility of Hong Kong AquaShield Health Technology Company Limited and Hong Kong AquaShield Health Technology Company Limited is the warrantor in relation to this product.

Rev A Sep 19

Nomor Tanda Pendaftaran: I.6.AI5.02604.0919

