
Always there to help you

Register your product and get support at www.philips.com/welcome


DS3205





Short User Manual







































Safety

Important Safety Instructions

- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been Environmental information exposed to rain or moisture, does not operate normally or has been dropped.
- Battery usage CAUTION To prevent battery leakage which may result in bodily injury, property damage, or damage to the clock radio:
- Do not mix batteries (old and new or carbon and alkaline, etc.).
- Install the battery correctly, + and as marked on the device.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
- Remove battery when the device is not used for a long time.
- Apparatus shall not be exposed to dripping or splashing.
- Do not place any sources of danger on the apparatus (e.g. liquid filled objects, lighted candles). equipment.
- Where the plug of the Direct Plug-in Adapter is used as the disconnect device, the disconnect device shall remain readily operable.



- Never remove the casing of this apparatus.
- Never lubricate any part of this apparatus. Never place this apparatus on other electrical equipment.
- Keep this apparatus away from direct sunlight, naked flames or heat.
- Make sure that you always have easy access to the power cord, plug, or adaptor to disconnect the apparatus from the power.

Notice

Any changes or modifications made to this device that are not expressly approved by Philips Consumer Lifestyle may void the user's authority to operate the equipment.

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products and batteries. The correct disposal of these products helps prevent potentially negative consequences on the environment and human health.

Your product contains batteries, which cannot be disposed of with normal household waste.

Please inform yourself about the local rules on separate collection of batteries. The correct disposal of batteries helps prevent potentially negative consequences on the environment and human health.

Please visit www.recycle.philips.com for additional information on a recycling center in your

Rated Output Power All unnecessary packaging has been omitted. We have tried to make the Signal to Noise packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.)

Your system consists of materials which can be recycled and reused if AC power (p disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old ____ Battery



The making of unauthorized copies of copy-protected material, including computer programs, files, broadcasts and sound recordings, may be an infringement of copyrights and constitute a criminal offence. This equipment should not be used for such purposes.



"Made for iPod" and "Made for iPhone" mean that an electronic accessory has been designed to connect specifically to iPod or iPhone respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod or iPhone may affect wireless performance.

The type plate is located on the bottom of the apparatus.

2 V E \M/ DMC

Amplifier

racea Oatpat i owei	27(3 ** 1(1)3	
Signal to Noise Ratio	85 dB	
		General
AC power (power adaptor)	OH-1018A1002000U-SAA(Philips) Input: 100-240 V~,50/60 Hz 650mA Output: 10 V 2 A	
Battery	4×AA	
Operation Power Consumption	18 W	
Dimensions - Main Unit	224 × 162 × 120 mm	
Weight - Main Unit	1.1 kg	



iPod and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries.

Power	Z X 3 VV KI*IS	
e Ratio	85 dB	
		General
ower adaptor)	OH-1018A1002000U-SAA(Philips) Input: 100-240 V~,50/60 Hz 650mA Output: 10 V 2 A	
	4×AA	
wer Consumption	18 W	
Main Unit	224 × 162 × 120 mm	
n Unit	1.1 kg	



Specifications are subject to change without notice © 2013 Koninklijke Philips Electronics N.V. All rights reserved.

DS3205_79_Short User Manual_V1.0

