



English

1. In standby mode, press and hold **PROG/CLOCK SET** to activate the clock setting mode.
2. Press **▲/▼** to select hour format.
3. Press **PROG/CLOCK SET** to confirm.
4. Repeat the above steps to set hour and minute.

简体中文

1. 在待机模式下，按住 **PROG/CLOCK SET** 启用时钟设置模式。
2. 按 **▲/▼** 可选择 时间格式。
3. 按 **PROG/CLOCK SET** 确认。
4. 重复上述设置小时和分钟。

English

Make sure that you have set the clock correctly.

1. In standby mode, press and hold **SLEEP/TIMER**.
2. Tap **SRC** repeatedly to select an alarm source.
3. Press **SLEEP/TIMER** to confirm.
4. Press **▲/▼** to set the hour.
5. Press **SLEEP/TIMER** to confirm.
6. Repeat the above steps to set minute and volume.

简体中文

确保您已正确设置时钟。

1. 待机模式下，按住**SLEEP/TIMER**。
2. 反复轻击 **SRC** 选择来源。
3. 按 **SLEEP/TIMER** 确认。
4. 按 **▲/▼** 可设置小时。
5. 按 **SLEEP/TIMER** 确认。
6. 重复上述步骤设置分钟和音量。

English

To download the full user manual, visit www.philips.com/support.

简体中文

要下载完整的用户手册，请访问 www.philips.com/support

English

1 Safety and Notice

Read and understand all instructions before you use this product. If damage is caused by failure to follow the instructions, the warranty does not apply.

Safety

Warning

- Never remove the casing of this apparatus.
- Never lubricate any part of this apparatus.
- Never place this apparatus on other electrical equipment.
- Keep this apparatus away from direct sunlight, naked flames or heat.
- Never look into the laser beam inside this apparatus.
- Ensure that you always have easy access to the power cord, plug or adaptor to disconnect this apparatus from the power.

- The device shall not exposed to dripping or splashing.
- Do no place any source of danger on the device (e.g. liquid filled objects, lit candles).
- Where the MAINS plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- Make sure that there is enough free space around the product for ventilation.
- Only use attachments/accessories specified by the manufacturer.

Disposal of your old product and batteries

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products and batteries. The correct disposal of these products helps prevent potentially negative consequences on the environment and human health.

Your product contains batteries, which cannot be disposed of with normal household waste.

Please inform yourself about the local rules on separate collection of batteries. The correct disposal of batteries helps prevent potentially negative consequences on the environment and human health.

Please visit www.recycle.philips.com for additional information on a recycling center in your area.

Compliance

This apparatus includes this label:



Note

- The type plate is located on the back of the apparatus.

Hearing safety



Warning

- To prevent possible hearing damage, do not listen at high volume levels for long periods.

- Listen at a moderate volume.**
- Using headphones at a high volume can impair your hearing. This product can produce sounds in decibel ranges that may cause hearing loss for a normal person, even for exposure less than a minute. The higher decibel ranges are offered for those that may have already experienced some hearing loss.
 - Sound can be deceiving. Over time, your hearing 'comfort level' adapts to higher volumes of sound. So after prolonged listening, what sounds 'normal' can actually be loud and harmful to your hearing. To guard against this, set your volume to a safe level before your hearing adapts and leave it there.
- To establish a safe volume level:**
- Set your volume control at a low setting.
 - Slowly increase the sound until you can hear it comfortably and clearly, without distortion.

- Listen for reasonable periods of time:**
- Prolonged exposure to sound, even at normally 'safe' levels, can also cause hearing loss.
 - Be sure to use your equipment reasonably and take appropriate breaks.
- Be sure to observe the following guidelines when using your headphones.**
- Listen at reasonable volumes for reasonable periods of time.
 - Be careful not to adjust the volume as your hearing adapts.
 - Do not turn up the volume so high that you can't hear what's around you.
 - You should use caution or temporarily discontinue use in potentially hazardous situations. Do not use headphones while operating a motorized vehicle, cycling, skateboarding, etc.; it may create a traffic hazard and is illegal in many areas.

Notice

Any changes or modifications made to this device that are not expressly approved by Philips Consumer Lifestyle may void the user's authority to operate the equipment.

Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet).

Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.



The making of unauthorized copies of copy-protected material, including computer programs, files, broadcasts and sound recordings, may be an infringement of copyrights and constitute a criminal offence. This equipment should not be used for such purposes.



Windows Media and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.



"Made for iPod", "Made for iPhone," and "Made for iPad" mean that an electronic accessory has been designed to connect specifically to iPod, iPhone, or iPad, respectively and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone, or iPad may affect wireless performance.

iPod and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. iPad is a trademark of Apple Inc.

Bluetooth

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Philips is under license.



© 2013 CSR plc and its group companies. The aptX® mark and the aptX logo are trade marks of CSR plc or one of its group companies and may be registered in one or more jurisdictions.

2 Product information

Note

- Product information is subject to change without prior notice.

Specifications

Amplifier	
Rated Output Power	130 W
Frequency Response	100 Hz - 16 kHz, ±3 dB
Signal to Noise Ratio	>70 dB
MP3 LINK Input	<600 mV RMS
Disc	
Laser Type	Semiconductor
Disc Diameter	12 cm
Support Disc	CD-DA, CD-R, CD-RW, MP3-CD, WMA-CD
Audio DAC	24 Bits / 44.1 kHz
Total Harmonic Distortion	<1%
Frequency Response	60 Hz -16 kHz (44.1 kHz)
S/N Ratio	>65 dBA
Tuner	
Tuning Range	FM: 87.5 - 108 MHz
Tuning grid	50 KHz
Sensitivity	- Mono, 26dB S/N Ratio - Stereo, 46dB S/N Ratio
Search Selectivity	<30 dBf
Total Harmonic Distortion	<3%
Signal to Noise Ratio	>70 dBA
Speakers	
Speaker Impedance	6 ohm + 3 x 6 ohm
Speaker Driver	5.25" woofer + 3 x 2.75" full range
Sensitivity	>82 dB/mW
General information	
AC power	220 - 240 V ~, 50/60 Hz
Standby Power Consumption	< 0.5 W
USB Direct	Version 2.0/1.1
Load of USB	≤500 mA
Dimensions	
- Main Unit (W x H x D)	300 x 994 x 300 mm
Weight	
- With Packing	12.5 kg
- Main Unit	10.2 kg
Bluetooth	
Standard	Bluetooth Standard/Version 2.1+EDR
Frequency band	2,402~2,480 GHz ISM Band
Range	10m (free space)

简体中文

1 安全和注意事项

请在使用本产品之前阅读并理解所有说明。因未遵守说明而造成的损坏不在保修范围内。

安全

警告

- 切勿拆下本产品的外壳。
- 切勿润滑本装置的任何部件。
- 切勿将本装置放在其它电路设备上。
- 应让本装置远离阳光直射、明火或高温。
- 切勿直视本装置内部的激光束。
- 确保始终可轻易地接触到电源线、电源插头或适配器，以便于将本装置从电源上断开。

- 切勿将设备暴露在不漏水或漏水环境下。
- 不要将任何危险源放在本设备上（例如装有液体的物体、点燃的蜡烛）。
- 将电源插头或产品耦合器用作断开设备时，该断开设备可以随时使用。
- 请确保产品周围有足够的空间进行通风。
- 仅使用制造商指定的附件/配件。
- 主插头用作断路装置，在不使用时应将插头拔掉，应保证与电网电源完全切断。
- 仅于海拔2000米以下地区使用该产品。



旧产品和电池的处置

本产品采用可回收利用的高性能材料和组件制造而成。

切勿将本产品与其它生活垃圾一起处理。请自行了解当地关于分类收集电子、电气产品及电池的规范。正确弃置这些产品有助于避免对环境 and 人体健康造成潜在的负面影响。

本产品所含的电池不能与一般的生活垃圾一同弃置。

请自行了解当地关于分类收集电池的规范。正确弃置电池有助于避免对环境 and 人类健康造成潜在的负面影响。

关于您所在地区回收中心的更多信息，请访问 www.recycle.philips.com。

合规性

本装置包括此标签：

Note

- 铭牌(铭牌上的信息包括工作电压、消耗功率)位于主机背面,使用前请了解铭牌上的相关信息。

听力安全



警告

- 为防止可能的听力受损，请勿长时间使用高音量收听。

- 以中等音量收听。
- 以高音量使用耳机会损坏您的听力。此产品产生的声音分贝范围可能导致正常人丧失听力，即使收听不到一分钟。较高的分贝范围适用于已经丧失了部分听力的人。
 - 声音是具有欺骗性的。随着时间的过去，您听力的“舒适级别”会要求较高的音量。因此，较长时间的收听之后，“正常”的音量实际上可能很大声，对您的听力有害。要防止此情况发生，请在您的听力适应之前，将音量设置到安全级别并保持不变。

- 要设置安全的音量级别：**
- 将音量控制设置为较低设置。
 - 慢慢调高声音，直到可以舒适、清晰地听见而不失真即可。
- 合理的收听时间：**
- 较长时间的收听，即使是正常的“安全”级别，也同样会导致听力受损。
 - 请确保合理使用设备，并进行适当的休息。
- 使用耳机时请确保遵循以下准则。**
- 在合理时间内以合理音量收听。
 - 听力适应后，请勿调节音量。
 - 不要将音量调得太高，以致于听不到周围的声音。
 - 在有潜在危险的情况下应谨慎使用或暂停使用。请勿在驾驶机动车、骑自行车、进行滑板运动等情况下使用耳机；否则可能会造成交通事故，而且这在许多地区属于非法行为。

注意

如果用户未经 Philips 优质生活部门的明确许可而擅自对此设备进行更改或修改，则可能导致其无权操作此设备。

环境信息

已省去所有不必要的包装。我们努力使包装易于分为三种材料：纸板（盒）、泡沫塑料（缓冲物）和聚乙烯（袋、保护性泡沫片）。

您的系统包含可回收利用的材料（如果由专业公司拆卸）。请遵守当地有关包装材料、废电池和旧设备的处理的规定。



进行受版权保护材料（包括计算机程序、文件、广播和录音）的未授权复制可能会侵犯版权并构成犯罪。不得将此设备用于这些目的。



Windows Media 和 Windows 徽标是 Microsoft Corporation 在美国和/或其它国家/地区的商标或注册商标。



"Made for iPod"、"Made for iPhone" 和 "Made for iPad" 表示电子附件专为连接 iPod、iPhone 或 iPad 而设计，并经开发人员认证，符合 Apple 性能标准。Apple 对该设备的操作及其是否符合安全和法规标准不负任何责任。请注意，通过 iPod、iPhone 或 iPad 使用该配件可能影响无线性能。

iPod 和 iPhone 是 Apple Inc. 在美国 和其它国家/地区注册的商标。iPad 是 Apple Inc. 的商标。

Bluetooth

蓝牙® 词汇和标识均为 Bluetooth SIG, Inc. 所有，Philips 对这些词汇和标识的任何使用均属合法。



© 2013 CSR plc 及其集团公司。aptX® 标志和 aptX 徽标均为 CSR plc 或其任一集团公司的商标，并且可能已在一个或多个司法管辖区注册。

2 产品信息

Note

- 产品信息如有更改，恕不另行通知。

规格

功放器	
额定输出功率	130 瓦
频率响应	100 赫兹 - 16 千赫，±3 dB
信噪比	>70 dB
MP3 LINK 输入	<600 毫伏 RMS
光盘	
激光类型	半导体
光盘直径	12 厘米
支持的光盘	CD-DA、CD-R、CD-RW、MP3-CD 和 WMA-CD
音频 DAC	24 位/44.1 千赫
总谐波失真	<1%
频率响应	60 赫兹 - 16 千赫 (44.1 千赫)

部件名称 Name of the Parts	有毒有害物质或元素 Hazardous/toxic Substance					
	铅 (Pb, Lead)	汞 (Hg, Mercury)	镉 (Cd, cadmium)	六价铬(Chromium 6+)	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
Housing 外壳	O	O	O	O	O	O
CD loader CD 光盘	X	O	O	O	O	O
LCD Panel 液晶面板	X	X	O	O	O	O
Loudspeakers 喇叭单元	O	O	O	O	O	O
PWBs 电路板组件	X	O	O	O	O	O
Accessories (Remote control & cables) 附件（遥控器，电 源线，连接线）	X	O	O	O	O	O
Batteries in Remote Control (ZnC) 遥控器电池	X	O	O	O	O	O

O：表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T11363 - 2006 标准规定的限量要求以下。

O:Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in SJ/T11363 — 2006.

×：表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363 — 2006 标准规定的限量要求。

X:Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in SJ/T11363 - 2006.

环保使用期限 Environmental Protection Use Period

This logo refers to the period (10 years)

电子信息产品中含有的有毒有害物质或元素在正常使用的条件下不会发生外泄或突变，电子信息产品用户使用该电子信息产品不会对环境造成严重污染或对其人身、财产造成严重 损害的期限。

This logo refers to the period (10 years) during which the toxic or hazardous substances or elements contained in electronic information products will not leak or mutate so that the use of these [substances or elements] will not result in any severe environmental pollution, any bodily injury or damage to any assets.