



## A Connect power




## B Set clock




### Note:

- You can set the clock in the standby mode only.
- 1 Press and hold **PROG/CLOCK SET** to enter the clock setting mode.
  - 2 Press **◀▶** to select **[Y]** or **[N]**.
    - **[Y]**: the unit reads the DAB/RDS time and sets the clock automatically.
    - **[N]**: the unit turns off the time synchronization.
  - 3 Press **PROG/CLOCK SET** to confirm.
  - 4 Press **◀▶** repeatedly to select 12 hour or 24 hour format.
  - 5 Press **PROG/CLOCK SET** to confirm.
  - 6 Press **◀▶** to set the hour.
  - 7 Press **PROG/CLOCK SET** to confirm.
  - 8 Press **◀▶** to set the minute.
  - 9 Press **PROG/CLOCK SET** to confirm the clock setting.


### C Play a disc




### E Play from USB



### D Listen to radio



### F Play iPod/iPhone





© 2010 Koninklijke Philips Electronics N.V.  
All rights reserved.

