

Philips Clock Radio

Compact design

A|3112

Start your day, your way!

Wake up with radio or buzzer

This stylish Philips clock radio looks nice and wakes you in time. It has built-in AM/FM radio and gives you a choice of waking up to your favorite station or the buzzer.

Start the day your way

- Wake up to your favorite radio tune or a buzzer
- \bullet Gentle wake for a pleasant wake up experience
- · Repeat alarm for additional snooze

Easy to use

- AM/ FM tuner for radio enjoyment
- · Big display for easy viewing
- Sleep timer for easy falling asleep to your favorite music
- Battery back-up ensures memory of time during power failure



Specifications

Convenience

- · Alarms: radio alarm, buzzer alarm, 24 hour alarm reset, repeat alarm (snooze)
- · Clock: Digital, sleep timer
- Display type: LED display

Sound

- · Sound system: mono
- Volume control: rotary (analogue)
- Output power: 100 mW RMS

Tuner/Reception/Transmission

- · Antenna: FM antenna
- Tuner bands: FM, AM

Accessories

- · Others: User Manual
- Warranty: Warranty Certificate





Dimensions

- Gross weight: 1.15 kg
- · Packaging type: D-box
- Product weight: 0.9 kg Main unit depth: 130 mm
- Main unit height: 56 mm
- Packaging width: 138 mm • Main unit width: 130 mm
- · Packaging height: 213 mm
- Packaging depth: 56 mm

Power

- Battery voltage: 9 V
- Battery type: 6F22 9V
- Number of batteries: 1
- Power type: AC Input

Highlights

Wake up to radio or a buzzer

Wake up to sounds from your favorite radio station or a buzzer. Simply set the alarm on your Philips Clock radio to wake you with the radio station you last listened to or choose to wake up with a buzzer sound. When the wake up time is reached, your Philips Clock radio will automatically turn on that radio station or trigger the buzzer to sound.

Gentle wake

Start your day right by waking up gently to a gradually escalating alarm volume. Normal alarm sounds with a preset volume are either too low to wake you up or are so uncomfortably loud that you are rudely jolted awake. Choose to wake up to your favorite music, radio station or buzzer alarm. Gentle wake's alarm volume gradually increases from subtly low to reasonably high in order to gently rouse you.

Battery back-upBattery back-up ensures memory of time during power failure



Issue date 2014-03-17

Version: 1.0.6

© 2014 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 51065 UPC: 6 09585 16783 4

www.philips.com