






A Connect power



B Set clock




Note:


- You can set the clock in the standby mode only.

- 1 Press and hold **PROG/CLOCK SET** to enter the clock setting mode.
- 2 Press **◀▶** to select **[Y]** or **[N]**.
 - **[Y]**: the unit reads the DAB/RDS time and sets the clock automatically.
 - **[N]**: the unit turns off the time synchronization.
- 3 Press **PROG/CLOCK SET** to confirm.
- 4 Press **◀▶** repeatedly to select 12 hour or 24 hour format.
- 5 Press **PROG/CLOCK SET** to confirm.
- 6 Press **◀▶** to set the hour.
- 7 Press **PROG/CLOCK SET** to confirm.
- 8 Press **◀▶** to set the minute.
- 9 Press **PROG/CLOCK SET** to confirm the clock setting.


C Play a disc




E Play from USB



D Listen to radio



F Play iPod/iPhone





© 2010 Koninklijke Philips Electronics N.V.
All rights reserved.

