




Clock Radio

AJ3540

Register your product and get support at
www.philips.com/welcome


Quick start guide 快速启用指南



Printed in China

AJ3540_96_QSG_V1.1

PHILIPS



ENGLISH

Step A

Power and switch on the radio

1. Remove the battery door to insert a **9 volts 6F22** type battery (not included) for clock memory backup.
2. Plug to the wall outlet.
3. Adjust **OFF/ON/AUTO/BUZZ** to **ON** to switch on the radio.

Step B

Setting the Clock & Alarm times

1. Hold down **SET TIME/ALARM OFF** or **SET ALARM 1** or **SET ALARM 2**.
2. Use **TIME SET ▲** or **▼** to adjust minute and/or hour.
3. Release **SET TIME/ALARM OFF** or **SET ALARM 1** or **SET ALARM 2**, and **TIME SET ▲** or **▼** when you reach the correct setting.
4. Repeat steps 1-3 for each of the clock or alarm settings.

Step C

Setting the Alarm mode

1. Adjust **AL1/AL2/AL1+2** to **AL1** (alarm 1), or **AL2** (alarm 2), or **AL1+2** (alarm 1 + alarm 2).
2. Select your choice of alarm mode by adjusting **OFF/ON/AUTO/BUZZ** to **AUTO** or **BUZZ**.

3 ways to switch off the alarm

Either press:

- **SET TIME/ALARM SET**

- **REPEAT ALARM**
- Or adjust **OFF/ON/AUTO/BUZZ** to **OFF**.

Special feature: SLEEP

This set has a built-in timer, which enables the set to be automatically switched off during radio playback after a set period of time.

1. Set **OFF/ON/AUTO/BUZZ** switch to **OFF** position.
2. Set your sleep time by pressing on the **SLEEP** button. Keep your finger on the button and the display will begin to count down from 0:59 to 0:00 minute.
→ To cancel sleep, press **SET TIME/ALARM OFF**.

中文

步驟 A

上電及開啟收音機

1. 取下電池蓋裝入 **9 伏特 6F22** 類型電池 (未隨附) 作為備份電力。
2. 將電源線插入電源插座。
3. 將 **OFF/ON/AUTO/BUZZ** 調整為 **ON** 開啟收音機。

步驟 B

設定時鐘 & 鬧鐘時間

1. 按住 **SET TIME/ALARM OFF** 或 **SET ALARM 1** 或 **SET ALARM 2**。
2. 按 **TIME SET ▲** 或 **▼** 調整分鐘和/或小時。
3. 調整至正確設定後，放開 **SET TIME/ALARM OFF** 或 **SET ALARM 1** 或 **SET ALARM 2**，和 **TIME SET ▲** 或 **▼**。
4. 重複步驟 1-3 設定時鐘或鬧鐘各種設置。

步驟 C

設定鬧鐘模式

1. 將 **AL1/AL2/AL1+2** 調整為 **AL1** (鬧鐘 1)，或 **AL2** (鬧鐘 2) 或 **AL1+2** (鬧鐘 1 + 鬧鐘 2)。
2. 將 **OFF/ON/AUTO/BUZZ** 為 **AUTO** 或 **BUZZ**，以選擇想要的鬧鐘模式。

關閉鬧鐘的三種方式

按：

- **SET TIME/ALARM SET**
- **REPEAT ALARM**
- 或將 **OFF/ON/AUTO/BUZZ** 調整至 **OFF** 位置。

特別功能：睡眠

本裝置內建定時器，可在設定時間內播放收音機，之後裝置會自動關閉。

1. 將 **OFF/ON/AUTO/BUZZ** 調至 **OFF** 的位置。
2. 按 **SLEEP** 按鈕，設定您的睡眠定時。按住按鈕不放，畫面會開始從 0:59 倒數至 0:00 分鐘。
→ 若要取消睡眠，按 **SET TIME/ALARM OFF**。